


Puxadores e asas de móvel
Tiradores y pomos de mueble
Furniture knobs and handles



linea
BERTOMANI®
DECO SINCE 1946


 PUXADOR DE MÓVEL
 POMO DE MUEBLE
 KNOB


 A B
 18 35

540.18.46-003

3393999014460



12 x1


 PUXADOR DE MÓVEL
 POMO DE MUEBLE
 KNOB


 A B
 13 29

600.13.46-003

3393999014651



12 x1


 PUXADOR DE MÓVEL
 POMO DE MUEBLE
 KNOB


 A B
 18 32

601.18.46-003

3393999014668



12 x1


 PUXADOR DE MÓVEL
 POMO DE MUEBLE
 KNOB

 A B
 12 20

602.12.46-003

3393999014682



12 x1


16 25


602.16.46-003

3393999014675



12 x1


 PUXADOR DE MÓVEL
 POMO DE MUEBLE
 KNOB

 A B
 12 20

603.9.46-003

3393999014705



12 x1


16 25


603.16.46-003

3393999014699



12 x1


 PUXADOR DE MÓVEL
 POMO DE MUEBLE
 KNOB


 A B
 14 25

604.14.46-003

3393999014712



12 x1


 PUXADOR DE MÓVEL
 POMO DE MUEBLE
 KNOB

 A B
 18 18

719.16.46-003

3393999014606



12 x1


24 19


719.25.46-003

3393999014491



12 x1


 PUXADOR DE MÓVEL
 POMO DE MUEBLE
 KNOB

 A B
 19 20

724.20.46-003

3393999014477



12 x1

25 20


724.25.46-003

3393999014484



12 x1


25 20


724.25.46-406

3393999562787




12 x6




PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A	B				
20	20		737.20.46-003	0083532080306	12 x1
25	26		737.25.46-003	0083532080344	12 x1




PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A	B				
25	30		740.25.46-003	0083532015483	12 x1
25	30		740.25.46-406	3393999562800	6 x6
40	44		740.40.46-003	0083532079645	12 x1




PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A	B				
17	27		748.46-003	0083532015681	12 x1




PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A	B				
15	26		749.15.46-003	0083532076231	12 x1
20	26		749.20.46-003	0083532077948	12 x1
20	26		749.20.46-306	3393999019403	6 x6
20	26		749.20.46-406	3393999040353	3 x6




PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A	B				
20	18		791.20.46-003	0083532065778	12 x1
25	20		791.25.46-003	0083532065785	12 x1




PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A	B				
18	28		792.46/2-003	0083532015018	12 x1
18	28		792.46/5-003	0083532015049	12 x1
18	28		792.46/7-003	0083532015186	12 x1




PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A	B				
16	20		793.16.46-003	0083532081389	12 x1
20	24		793.20.46-003	0083532081396	12 x1
23	28		793.23.46-003	0083532081266	12 x1




PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A	B					
13	30		795.13.46-003	0083532081402		12 x1
16	32		795.16.46-003	0083532081488		12 x1
19	32		795.19.46-003	0083532081273		12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A	B					
15	30		797.15.46-003	0083532097076		12 x1
20	33		797.20.46-003	0083532097083		12 x1




PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A	B					
20	20		799.20.46-003	3393999014446		12 x1
30	25		799.30.46-003	3393999014453		12 x1




ASA DE MÓVEL OCO
TIRADOR DE MUEBLE HUECO
HANDLE

A	B					
96	10		1146.96.46-003	3393999039142		12 x1
96	10		1146.96.46-405	3393999040360		3 x5
128	10		1146.128.46-003	3393999039159		12 x1
128	10		1146.128.46-405	3393999553020		3 x5
128	10		1146.160.46-003	3393999039166		12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A	B					
96	10		1147.96.46-003	3393999039173		12 x1
96	10		1147.96.46-405	3393999553037		3 x5
128	10		1147.128.46-003	3393999039180		12 x1
128	10		1147.128.46-405	3393999553044		3 x5
160	10		1147.160.46-003	3393999039197		6 x1
192	10		1147.192.46-003	3393999039203		6 x1




ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A	B					
64	8		140.64.46-003	0083532014462		12 x1
96	8		140.96.46-003	0083532014493		12 x1
96	8		140.96.46-306	3393999654147		6 x6
128	8		140.128.46-003	0083532014554		12 x1
160	8		140.160.46-003	0083532014738		6 x1
192	8		140.192.46-003	0083532014745		6 x1




ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A	B				
96	12		146.96.46-003	0083532057346	12 x1
128	12		146.128.46-003	0083532057360	12 x1
160	12		146.160.46-003	0083532057377	12 x1
192	12		146.192.46-003	0083532057391	12 x1




ASA DE MÓVEL OCO
TIRADOR DE MUEBLE HUECO
HANDLE

A	B				
64	10		1849.64.46-003	3393999039036	12 x1
64	10		1849.64.46-405	3393999553006	3 x5
96	10		1849.96.46-003	3393999039043	12 x1
96	10		1849.96.46-405	3393999552993	3 x5
128	10		1849.128.46-003	3393999039050	12 x1
160	10		1849.160.46-003	3393999039067	6 x1
192	10		1849.192.46-003	3393999039074	6 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A	B	C			
91	64	10		213.64.46/5-003	0083532048818 12 x1
121	96	10		213.96.46/5-003	0083532048634 12 x1
154	128	10		213.128.46/5-003	0083532048290 12 x1




ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A	B				
96	8		260.96.46-003	3393999014415	12 x1
128	8		260.128.46-003	3393999014361	12 x1
160	8		260.160.46-003	3393999014392	6 x1
242	8		260.242.46-003	3393999014408	6 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A	B				
96	8		738.96.46-003	0083532015391	12 x1
128	8		738.128.46-003	0083532015261	12 x1




ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE


A	B				
96	10		739.96.46-003	0083532080115	12 x1
128	10		739.128.46-003	0083532080207	12 x1
160	10		739.160.46-003	0083532080597	6 x1


 ASA DE MÓVEL
 TIRADOR DE MUEBLE
 HANDLE


A	B	C					
160	128	10		792.128.46/2-003	0083532093504		12 x1
160	128	10		792.128.46/5-003	0083532015223		12 x1
160	128	10		792.128.46/7-003	0083532097557		12 x1


 ASA DE MÓVEL
 TIRADOR DE MUEBLE
 HANDLE


A	B	C					
98	64	10		792.64.46/2-003	0083532093474		12 x1
98	64	10		792.64.46/5-003	0083532016121		12 x1
98	64	10		792.64.46/7-003	0083532027059		12 x1
130	96	10		792.96.46/2-003	0083532093443		12 x1
130	96	10		792.96.46/5-003	0083532016459		12 x1
130	96	10		792.96.46/7-003	0083532027028		12 x1


 ASA DE MÓVEL
 TIRADOR DE MUEBLE
 HANDLE

A							
64		845.64.46-003	0083532085004		12	x1	
96		845.96.46-003	0083532084830		12	x1	
128		845.128.46-003	0083532084847		12	x1	
160		845.160.46-003	0083532084861		12	x1	
192		845.192.46-003	0083532084878		12	x1	
242		845.242.46-003	0083532084885		12	x1	


 ASA DE MÓVEL
 TIRADOR DE MUEBLE
 HANDLE

A	B						
64	100		846.100.46-003	3393999032327		12	x1



 ASA DE MÓVEL
 TIRADOR DE MUEBLE
 HANDLE

A	B						
64	10		849.64.46-003	0083532089194		12	x1
96	10		849.96.46-003	0083532089088		12	x1
128	10		849.128.46-003	0083532089095		12	x1
160	10		849.160.46-003	0083532089019		12	x1
192	10		849.192.46-003	0083532089101		12	x1
242	10		849.242.46-003	0083532089132		12	x1
320	10		849.320.46-003	0083532089149		12	x1
392	10		849.392.46-003	0083532089156		12	x1
492	10		849.492.46-003	0083532089163		12	x1
592	10		849.592.46-003	0083532089170		12	x1




ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A	B				
96	12		850.96.46-003	0083532096079	12 x1
128	12		850.128.46-003	0083532096086	12 x1
160	12		850.160.46-003	0083532096093	12 x1
192	12		850.192.46-003	0083532096109	6 x1
242	12		850.242.46-003	0083532096116	6 x1
320	12		850.320.46-003	0083532096147	6 x1
392	12		850.392.46-003	0083532096154	6 x1
492	12		850.492.46-003	0083532096161	6 x1
592	12		850.592.46-003	0083532096178	6 x1
692	12		850.692.46-003	0083532096185	6 x1
792	12		850.792.46-003	0083532096192	6 x1




ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A	B				
96	14		851.96.46-003	0083532054505	12 x1
128	14		851.128.46-003	0083532054765	12 x1
160	14		851.160.46-003	0083532054864	6 x1
192	14		851.192.46-003	0083532054895	6 x1
242	14		851.242.46-003	0083532064207	6 x1
320	14		851.320.46-003	0083532054932	6 x1
392	14		851.392.46-003	0083532055021	6 x1
492	14		851.492.46-003	0083532055038	6 x1
592	14		851.592.46-003	0083532055069	6 x1
692	14		851.692.46-003	0083532055090	6 x1
792	14		851.792.46-003	0083532055113	6 x1




ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A	B				
64	8		854.64.46-003	0083532064832	12 x1
96	8		854.96.46-003	0083532064849	12 x1
128	8		854.128.46-003	0083532064856	12 x1




ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A	B				
64	10		855.64.46-003	0083532095997	12 x1
96	10		855.96.46-003	0083532096000	12 x1
128	10		855.128.46-003	0083532096017	12 x1
160	10		855.160.46-003	0083532096024	6 x1
192	10		855.192.46-003	0083532096031	6 x1




ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A	B				
96	10		857.96.46-003	0083532096048	12 x1
128	10		857.128.46-003	0083532096055	12 x1
160	10		857.160.46-003	0083532096062	12 x1




ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A	B					
64	8		858.64.46-003	0083532080924		12 x1
96	8		858.96.46-003	0083532080948		12 x1
128	8		858.128.46-003	0083532080962		12 x1
160	8		858.160.46-003	0083532081006		6 x1
192	8		858.192.46-003	0083532081082		6 x1
242	8		858.242.46-003	0083532081105		6 x1
320	8		858.320.46-003	0083532081112		6 x1
392	8		858.392.46-003	0083532081129		6 x1
492	8		858.492.46-003	0083532081136		6 x1
592	8		858.592.46-003	0083532081174		6 x1




ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A	B					
64	8		859.64.46-003	0083532081204		12 x1
96	8		859.96.46-003	0083532081211		12 x1
128	8		859.128.46-003	0083532081228		12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A	B					
64-96	10		865.64-96.46-003	0083532081242		12 x1
96-128	10		865.96-128.46-003	0083532081259		12 x1
128-160	10		865.128-160.46-003	0083532081426		6 x1




PORTA-ETIQUETAS
PUERTA-ETIQUETAS
LABEL HOLDER

A	B	C				
60	20	45x8		373.60.46-003	0083532050569	12 x4
80	30	60x15		373.80.46-003	0083532050606	12 x4
80	30	60x15		373.80.46-009	3393999133314	12 x4




ENTRADA DE CHAVE
BOCALLAVE
ROUND ESCUTCHEON

A						
30		751.46-003	0083532066980		12 x1	




PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A					
25		1176.17-003	0083532064184		12 x1
20		1176.40-003	0083532064191		12 x1





PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A	B				
20	28		123.20.13-003	0083532073018	12 x1




PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A	B				
20	28		123.20.16-003	0083532073070	12 x1




PUXADOR DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A					
32		1246.32.16-003	3393992572998		12 x1




PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A	B				
25	30		1248.16-003	0083532059180	12 x1




PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A	B				
17	25		1249.18.18-003	0083532068885	12 x1




PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A	B				
10	25		1250.10.16-003	0083532073117	12 x1
15	25		1250.15.16-003	0083532073148	12 x1
20	25		1250.20.16-003	0083532073162	12 x1




PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A	B				
13	30		1251.13.16-003	0083532073209	12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

60  **1299.60.18-003** 3393999039678  **12 x1**




PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

12 **24**  **1306.18-003** 0083532058435  **12 x1**



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

20 **35** **20**  **1307.18-003** 0083532058527  **12 x1**



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

7 **34**  **1310.18-003** 0083532069271  **12 x1**




PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

32  **1754.32.40-003** 0083532064221  **12 x1**




PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

40  **1758.40.40-003** 0083532097090  **12 x1**




PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

30 **20**  **414.30.26-003** 0083532054376  **12 x1**
40 **22**  **414.40.26-003** 0083532054406  **12 x1**



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

15 **20**  **805.15.26-003** 0083532036525  **12 x1**



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
18 25




806.18.26-003

0083532036600



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
22 30




808.30.26-003

0083532036556



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
25 34




809.34.26-003

0083532036655



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
25 30




810.25.26-003

0083532036495



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
18 24



811.18.26-003

0083532036624



12 x1

18 24



811.18.26-306

3393999552771



6 x6

18 24




811.18.26-406

3393999654666



3 x6



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
20 18



812.20.26-003

0083532057445



12 x1

25 20




812.25.26-003

0083532057438



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
18 21




816.18.26-003

0083532057407



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
30 30



8599.30.26/69-003

3393992639844



12 x1

30 30



8599.30.26/70-003

3393992639820



12 x1

30 30




8599.30.26/95-003

3393992639837




12 x1




PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A	B					
28	29		985.12-003	0083532054871		12 x1
28	29		985.16-003	0083532054925		12 x1




ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A	B					
160	13		120.160.18-003	0083532031131		12 x1
192	13		120.192.18-003	0083532097144		12 x1
256	13		120.256.18-003	0083532097137		12 x1




ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A						
64		124.64.16-003	0083532073100		12	x1




ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A	B					
64	7		140.64.13-003	0083532017197		12 x1
96	7		140.96.13-003	0083532017531		12 x1
128	7		140.128.13-003	0083532075203		12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A	B					
64	7		140.64.16-003	0083532017241		12 x1
96	7		140.96.16-003	0083532017586		12 x1
128	7		140.128.16-003	0083532075104		12 x1




ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A						
32		1400.26-003	0083532057490		12	x1




ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A						
32		1401.26-003	0083532057506		12	x1




ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A						
32		1402.26-003	0083532057520		12	x1




ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A				
64		1756.64.40-003	0083532064399	12 x1




ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A				
64		1760.96.40-003	0083532097113	12 x1
96		1760.128.40-003	0083532097106	12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A				
120		400.120.26-003	0083532052006	12 x1
160		400.160.26-003	0083532052037	12 x1




ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A				
96		402.96.26-003	0083532032381	12 x1
128		402.128.26-003	0083532032732	12 x1
160		402.160.26-003	0083532033630	10 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A				
70		403.70.24-003	0083532053317	12 x1
70		403.70.26-003	0083532053348	12 x1
90		403.90.24-003	0083532053379	12 x1
90		403.90.26-003	0083532053409	12 x1
90		403.90.26-036	3393999040643	6 x6




ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A	B			
192	23		404.192.26-003	0083532033739 12 x1
224	23		404.224.26-003	0083532033784 12 x1
320	23		404.320.26-003	0083532033852 12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE


A	B			
128	14		405.128.26-003	0083532034019 12 x1
128	14		405.128.26-405	3393999654673 3 x5
160	14		405.160.26-003	0083532034156 12 x1
192	14		405.192.26-003	0083532034217 12 x1
224	14		405.224.26-003	0083532034262 12 x1


 ASA DE MÓVEL
 TIRADOR DE MUEBLE
 HANDLE


A					
96		406.96.26-003	0083532034293		12 x1
128		406.128.26-003	0083532034354		12 x1
160		406.160.26-003	0083532034484		12 x1
192		406.192.26-003	0083532034538		12 x1


 ASA DE MÓVEL
 TIRADOR DE MUEBLE
 HANDLE


A	B				
64	10		408.64.26-003	0083532035078	12 x1
96	10		408.96.26-003	0083532034644	12 x1
96	10		408.96.26-306	3393999019380	6 x6
128	10		408.128.26-003	0083532034675	12 x1
160	10		408.160.26-003	0083532034729	12 x1
192	10		408.192.26-003	0083532034736	12 x1
242	10		408.242.26-003	0083532034781	12 x1
320	10		408.320.26-003	0083532034842	12 x1
392	10		408.392.26-003	0083532035122	12 x1
492	10		408.492.26-003	0083532035139	12 x1
592	10		408.592.26-003	0083532035146	12 x1
692	10		408.692.26-003	0083532035269	12 x1
792	10		408.792.26-003	0083532035276	6 x1


 ASA DE MÓVEL
 TIRADOR DE MUEBLE
 HANDLE

A					
32		409.32.26-003	0083532034859		12 x1
64		409.64.26-003	0083532034866		12 x1
96		409.96.26-003	0083532034873		12 x1
128		409.128.26-003	0083532034880		12 x1
160		409.160.26-003	0083532034897		12 x1


 ASA DE MÓVEL
 TIRADOR DE MUEBLE
 HANDLE

A					
64		410.64.26-003	0083532069660		12 x1
96		410.96.26-003	0083532069776		12 x1
128		410.128.26-003	0083532069622		12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
25 19




1150.25.3-003

0083532000915



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
25 30
30 30



1160.25.3-003

0083532005392



12 x1




1160.30.3-003

0083532005583



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
25 20




1172.25.16-003

0083532058725



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
24 18
32 26



1173.24.3-003

0083532058756



12 x1




1173.32.3-003

0083532058787



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
15 20
18 24



1175.15.3-003

0083532096550



12 x1




1175.18.3-003

0083532096581



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
18 25




1179.3-003

0083532079133



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
33 30




1181.33.3-003

0083532059005



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B C
18 50 25




1184.50.16-003

0083532072639




12 x1


 PUXADOR DE MÓVEL
 POMO DE MUEBLE
 KNOB

A	B		1283.40-003	0083532058862		12 x1
28	30					


 PUXADOR DE MÓVEL
 POMO DE MUEBLE
 KNOB


A	B		1296.16-003	3393992583567		12 x1
23	35					


 PUXADOR DE MÓVEL
 POMO DE MUEBLE
 KNOB


A	B		1382.16-003	3393992618399		12 x1
25	17					


 PUXADOR DE MÓVEL
 POMO DE MUEBLE
 KNOB


A	B		1385.16-003	3393992618474		12 x1
22	28					


 PUXADOR DE MÓVEL
 POMO DE MUEBLE
 KNOB


A	B		1390.30.16-003	0083532088630		12 x1
20	29					


 PUXADOR DE MÓVEL
 POMO DE MUEBLE
 KNOB

A	B		1398.30.16-003	0083532073254		12 x1
32	26					


 PUXADOR DE MÓVEL
 POMO DE MUEBLE
 KNOB

A	B		1817.57-003	3393992652881		12 x1
32	25					


 PUXADOR DE MÓVEL
 POMO DE MUEBLE
 KNOB

A	B		1818.57-003	3393992652904		12 x1
32	27					



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
40 60




184.16-003

0083532037591



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
30 20




233.30.16-003

0083532061695



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
25 17



324.25.16-003

0083532046050



12 x1

35 18




324.35.16-003

0083532046210



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
30




3503.30.16-003

3393999039432



6 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
30 21



563.30.16-003

0083532070536



12 x1

40 22



563.40.16-003

0083532070789



12 x1

80




563.80.16-003

0083532070994



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
24 25



744.24.3-003

0083532016817



12 x1

29 30




744.29.3-003

0083532016626



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
30 19



763.30.16-003

0083532096246



12 x1

30 19




763.30.16-406

3393999040407



3 x6



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B C
21 32 21




803.16-003

0083532060179



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
17 32




804.16-003

0083532060209



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A
25




814.25.16-003

0083532058893



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
30 25




839.30.16-003

0083532059159



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
32 19




840.30.16-003

0083532059029



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
20 20




841.20.16-003

0083532059012



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
25 22



842.25.16-003

0083532058985



12 x1

25 22





842.25.16-406

3393999040384



3 x6



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
20 20




899.20.3-003

3393999015078



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
24 25



1303.24.18-003

0083532058046



12 x1

28 30




1303.28.18-003

0083532058077



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B C
15 50 25




1304.18-003

0083532058176



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
30 30





1311.30.18-003

0083532073223



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A
35




1403.35.18-003

3393999039630



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
CUPPED HANDLE

A B
35 40




154.40.18-003

0083532062241



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
23 25




813.18-003

0083532058275



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
25 20




815.18-003

0083532058367



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
20 14




819.18-003

0083532057872



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
10 19




820.10.18-003

0083532057834




12 x1




PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A	B					
20	25		821.20.18-003	0083532057797		12 x1
20	25		821.20.18-036	3393999040629		6 x6
25	30		821.25.18-003	0083532057957		12 x1




PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A	B					
25	20		823.25.18-003	0083532060254		12 x1
30	25		823.30.18-003	0083532069615		12 x1




PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A	B					
25	23		824.25.18-003	0083532057964		12 x1
25	23		824.25.18-036	3393999040612		6 x6
30	25		824.30.18-003	0083532057995		12 x1
30	25		824.30.18-306	3393999018734		6 x6




PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A	B					
12	20		800.12.26-003	0083532069875		12 x1
12	20		800.12.26-306	3393999019410		6 x6




PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A	B					
30	20		1150.30.5-003	0083532001165		12 x1




PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A	B					
25	30		1160.25.5-003	0083532005378		12 x1
30	30		1160.30.5-003	0083532005484		12 x1




PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A	B					
15	25		1174.15.13-003	0083532059739		12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A	B					
15	20		1175.15.5-003	0083532096543		12 x1
18	24		1175.18.5-003	0083532096574		12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
15 24




1178.5-003

0083532079126



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
35 32




1380.13-003

3393992618351



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B C
18 18 23




1383.13-003

3393992618412



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
20 18




141.5-003

0083532017722



12 x1



PUXADOR DE MÓVEL ENCASTRAR
POMO DE MUEBLE ENCASTRAR
CUPPED HANDLE

A B
35 40



154.40.13-003

0083532062203



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
40 60




184.13-003

0083532037546



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
25 17



324.25.13-003

0083532045992



12 x1

35 18




324.35.13-003

0083532046159



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
25 20



330.25.5-003

0083532046982



12 x1

30 24




330.30.5-003


0083532047071




12 x1


 PUXADOR DE MÓVEL
 POMO DE MUEBLE
 KNOB

A	B				
30	21		563.30.13-003	0083532070468	12 x1
40	22		563.40.13-003	0083532070703	12 x1


 PUXADOR DE MÓVEL
 POMO DE MUEBLE
 KNOB


A	B				
28	20		686.28.13-003	0083532061114	12 x1
28	20		686.28.13-406	3393999040391	3 x6
32	25		686.32.13-003	0083532061497	12 x1


 PUXADOR DE MÓVEL
 POMO DE MUEBLE
 KNOB


A	B				
24	25		744.24.5-003	0083532016787	12 x1
29	30		744.29.5-003	0083532016510	12 x1


 PUXADOR DE MÓVEL
 POMO DE MUEBLE
 KNOB


A					
45		8596.1.13-003	3393992591838		12 x1


 PUXADOR DE MÓVEL
 POMO DE MUEBLE
 KNOB


A	B				
23	26		115.2-003	0083532014516	12 x1


 PUXADOR DE MÓVEL
 POMO DE MUEBLE
 KNOB


A	B				
25	19		1150.25.2-003	0083532000038	12 x1
30	20		1150.30.2-003	0083532000953	12 x1


 PUXADOR DE MÓVEL
 POMO DE MUEBLE
 KNOB

A	B				
25	26		1154.25.2-003	0083532002360	12 x1
30	26		1154.30.2-003	0083532003138	12 x1


 PUXADOR DE MÓVEL
 POMO DE MUEBLE
 KNOB

A	B				
25	30		1160.25.2-003	0083532005354	12 x1
30	30		1160.30.2-003	0083532005422	12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B

30 35



1162.30.2-003

0083532005606



12 x1

35 35




1162.35.2-003

0083532006641



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B

15 25




1174.15.12-003

0083532059678



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B

15 20



1175.15.2-003

0083532096536



12 x1

18 24




1175.18.2-003

0083532096567



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B

25 20



1177.25.2-003

0083532096604



12 x1

30 20




1177.30.2-003

0083532096765



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B

25 23



118.25.2-003

0083532060773



12 x1

30 25




118.30.2-003

0083532060797



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B

12 10



138.10.2-003

0083532016282



12 x1

18 12



138.12.2-003

0083532016312



12 x1

20 14



138.18.2-003

0083532016374



12 x1

25 15



138.20.2-003

0083532016404



12 x1

30 16



138.25.2-003

0083532016435



12 x1

35 20



138.30.2-003

0083532016466



12 x1

35 20




138.35.2-003

0083532016497



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B

20 18




141.2-003

0083532017692




12 x1




PUXADOR DE MÓVEL
 POMO DE MUEBLE
 CUPPED HANDLE

A	B				
35	40		154.40.12-003	0083532061725	12 x1




PUXADOR DE MÓVEL
 POMO DE MUEBLE
 KNOB

A	B				
25	22		183.25.2-003	0083532022993	12 x1




PUXADOR DE MÓVEL
 POMO DE MUEBLE
 KNOB

A	B				
20	18		200.20.2-003	0083532023990	12 x1
30	19		200.30.2-003	0083532024119	12 x1
40	20		200.40.2-003	0083532024171	12 x1




PUXADOR DE MÓVEL
 POMO DE MUEBLE
 KNOB

A	B				
30	24		231.30.12-003	0083532036648	12 x1
40	27		231.40.12-003	0083532036815	12 x1





PUXADOR DE MÓVEL
 POMO DE MUEBLE
 KNOB

A	B				
25	25		296.25.2-003	0083532044582	12 x1
30	30		296.30.2-003	0083532044629	12 x1




PUXADOR DE MÓVEL
 POMO DE MUEBLE
 KNOB

A	B				
20	15		297.20.2-003	0083532044667	12 x1
25	16		297.25.2-003	0083532044698	12 x1
30	19		297.30.2-003	0083532044728	12 x1




PUXADOR DE MÓVEL
 POMO DE MUEBLE
 KNOB

A	B				
23	21		298.2-003	0083532044759	12 x1



PUXADOR DE MÓVEL
 POMO DE MUEBLE
 KNOB

A	B				
25	23		299.25.2-003	0083532044780	12 x1
30	25		299.30.2-003	0083532044810	12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
22 25




300.2-003

0083532044841



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
25 17



324.25.12-003

0083532045961



12 x1

35 18




324.35.12-003

0083532046128



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
25 20



330.25.2-003

0083532046944



12 x1

30 24




330.30.2-003

0083532047019



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
25 22




353.25.12-003

0083532098394



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
30 21



563.30.12-003

0083532070420



12 x1

40 22




563.40.12-003

0083532070659



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
30 24



629.30.2-003

3393992542632



12 x1

38 30




629.38.2-003

3393992546869



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
25 19



630.25.2-003

0083532076897



12 x1

28 23



630.28.2-003

0083532076927



12 x1

35 25



630.35.2-003

0083532076958



12 x1

40 27




630.40.2-003


0083532076989




12 x1


 PUXADOR DE MÓVEL
 POMO DE MUEBLE
 KNOB


A	B					
30	26		65.30.2-002	3393999592104		10 x1
30	26		65.30.2-003	0083532077955		12 x1
38	26		65.38.2-002	3393999580712		10 x1
38	26		65.38.2-003	0083532077986		12 x1


 PUXADOR DE MÓVEL
 POMO DE MUEBLE
 KNOB


A	B					
25	27		66.25.2-003	0083532078266		12 x1
32	32		66.32.2-003	0083532078297		12 x1


 PUXADOR DE MÓVEL
 POMO DE MUEBLE
 KNOB


A	B					
28	20		686.28.12-003	0083532061053		12 x1
28	20		686.28.12-406	3393999040506		3 x6
32	25		686.32.12-003	0083532061459		12 x1


 PUXADOR DE MÓVEL
 POMO DE MUEBLE
 KNOB


A	B					
30	20		730.30.2-003	0083532082751		12 x1
35	22		730.35.2-003	0083532082812		12 x1
45	25		730.45.2-003	0083532082874		12 x1


 PUXADOR DE MÓVEL
 POMO DE MUEBLE
 KNOB



A	B					
24	25		744.24.2-003	0083532016671		12 x1
29	30		744.29.2-003	0083532016480		12 x1


 PUXADOR DE MÓVEL
 POMO DE MUEBLE
 KNOB

A	B					
30	23		758.30.2-003	0083532056844		12 x1


 PUXADOR DE MÓVEL
 POMO DE MUEBLE
 KNOB

A	B					
25	23		824.25.12-003	0083532071083		12 x1
30	25		824.30.12-003	0083532071106		12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
20 20




899.20.2-003

3393999015030



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
25 20



919.25.2-003

0083532044902



12 x1

30 24



919.30.2-003

0083532044964



12 x1

35 28




919.35.2-003

0083532045022



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
20 18



920.15.2-003

0083532045053



12 x1

20 18



920.20.2-003

0083532045114



12 x1

25 20



920.25.2-003

0083532045169



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB + ROSE

A B
30 107




966.12-003

3393999651146



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B C
23 32 35




983.2-003

0083532052969



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
35 31




984.41-003

3393992721686



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
25 32




986.41-003

0083532033524



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
30 43




987.41-003

0083532033432



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
24 36




988.41-003

0083532033494



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
25 26



1154.25.1-003

0083532002438



12 x1

30 26




1154.30.1-003

0083532003220



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
35 35




1162.35.1-003

0083532006146



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
25 20



1177.25.1-003

0083532096598



12 x1

30 20




1177.30.1-003

0083532096758



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
25 23



118.25.1-003

0083532058800



12 x1

30 25




118.30.1-003

0083532058817



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
25 19



121.25.1-003

0083532064894



12 x1

30 20




121.30.1-003

0083532064917



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
25 20



122.25.11-003

0083532072653



12 x1

25 20




122.25.11-406

3393999040490



3 x6



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
20 18



200.20.1-003

0083532023969



12 x1

30 19



200.30.1-003

0083532024089



12 x1

40 20



200.40.1-003

0083532024140



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B C
21 35 8




214.35.11-003

0083532031803



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B

30 24



231.30.11-003

0083532036594



12 x1

40 27




231.40.11-003

0083532036785



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B

30 20




233.30.11-003

0083532061596



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B

35 20




336.11-003

0083532071823



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B

25 22




353.25.11-003

0083532098400



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B

30 21



364.30.59-003

0083532050163



12 x1

40 24




364.40.59-003

0083532050194



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B

30 20



422.30.1-003

0083532087350



12 x1

35 22




422.35.1-003

0083532087510



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B

25 22



437.25.1-003

0083532058398



12 x1

30 23




437.30.1-003


0083532058428




24 x1


 PUXADOR DE MÓVEL
 POMO DE MUEBLE
 KNOB


A	B					
28	20		686.28.11-003	0083532060926		12 x1
32	25		686.32.11-003	0083532061428		12 x1


 PUXADOR DE MÓVEL
 POMO DE MUEBLE
 KNOB


A	B					
33	25		687.1-003	0083532078549		12 x1


 PUXADOR DE MÓVEL
 POMO DE MUEBLE
 KNOB


A	B					
30	20		730.30.1-003	0083532082720		12 x1
35	22		730.35.1-003	0083532082782		12 x1
45	25		730.45.1-003	0083532082843		12 x1


 PUXADOR DE MÓVEL
 POMO DE MUEBLE
 KNOB DIRECTOIRE


A	B					
25	15		756.25.1-003	0083532056783		12 x1
30	22		756.30.1-003	0083532056790		12 x1


 PUXADOR DE MÓVEL
 POMO DE MUEBLE
 KNOB


A	B					
30	23		758.30.1-003	0083532056820		12 x1


 PUXADOR DE MÓVEL LOUIS XVI
 POMO DE MUEBLE LOUIS XVI
 KNOB LOUIS XV


A	B					
25	21		761.25.1-003	0083532057186		12 x1
30	26		761.30.1-003	0083532057209		12 x1


 PUXADOR DE MÓVEL
 POMO DE MUEBLE
 KNOB

A	B					
30	29		770.11-003	0083532083901		12 x1


 PUXADOR DE MÓVEL
 POMO DE MUEBLE
 KNOB

A	B					
30	21		771.30.11-003	0083532084281		12 x1
35	21		771.35.11-003	0083532095362		12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
25 25




779.25.11-003

0083532073759



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
30 25




781.30.11-003

0083532073896



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
25 20



919.25.1-003

0083532044872



12 x1

30 24



919.30.1-003

0083532044933



12 x1

35 28




919.35.1-003

0083532044995



12 x1



PUXADOR DE MÓVEL + ROSETA
POMO DE MUEBLE + ROSETA
KNOB + ROSE

A B
30 107




966.11-003

0083532052976



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
28 22



686.28.31-003

0083532061176



12 x1

32 26




686.32.31-003

0083532061510



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
30 21




780.30.17-003

0083532084892



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
HANDLE

A B
30 21




780.30.31-003

0083532084960



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
30 27




781.30.31-003

0083532077306




12 x1




PUXADOR DE MÓVEL
 POMO DE MUEBLE
 PORCELAIN KNOB

A	B					
30	25		1651.1.16-003	0083532091265		12 x1
30	25		1651.1.16-306	3393999553747		6 x6
30	25		1651.1.16-406	3393999040452		3 x6





PUXADOR DE MÓVEL
 POMO DE MUEBLE
 PORCELAIN KNOB

A	B					
30	25		1651.2.16-003	0083532091272		12 x1




PUXADOR DE MÓVEL
 POMO DE MUEBLE
 PORCELAIN KNOB

A	B					
30	25		1651.3.16-003	0083532091289		12 x1




PUXADOR DE MÓVEL
 POMO DE MUEBLE
 PORCELAIN KNOB

A	B					
26	25		1804.69-003	3393992652669		6 x1




PUXADOR DE MÓVEL
 POMO DE MUEBLE
 PORCELAIN KNOB

A	B					
25	30		2025.25.38-003	0083532001660		12 x1
30	38		2025.30.38-003	0083532001684		12 x1
35	40		2025.35.38-003	0083532003244		12 x1




PUXADOR DE MÓVEL
 POMO DE MUEBLE
 PORCELAIN KNOB

A	B	C				
32	22	35		2026.38-003	0083532003251	12 x1



PUXADOR DE MÓVEL
 POMO DE MUEBLE
 PORCELAIN KNOB

A	B					
30	26		2035.30.37-003	0083532013991		12 x1
30	26		2035.30.37-406	3393999040469		3 x6




PUXADOR DE MÓVEL
 POMO DE MUEBLE
 PORCELAIN KNOB

A	B	C				
32	22	35		2045.37-003	0083532083888	12 x1



1



PUXADOR DE MÓVEL
POMO DE MUEBLE
PORCELAIN KNOB

A B
30 35



2048.1.37-003


0083532037621



12 x1



2



PUXADOR DE MÓVEL
POMO DE MUEBLE
PORCELAIN KNOB

A B
30 35



2048.2.37-003


0083532037645



12 x1



3



PUXADOR DE MÓVEL
POMO DE MUEBLE
PORCELAIN KNOB

A B
30 35



2048.3.37-003


0083532037713



12 x1



4



PUXADOR DE MÓVEL
POMO DE MUEBLE
PORCELAIN KNOB

A B
30 35



2048.4.37-003


0083532037720



12 x1



5



PUXADOR DE MÓVEL
POMO DE MUEBLE
PORCELAIN KNOB

A B
30 35



2048.5.37-003


0083532059036



12 x1



6



PUXADOR DE MÓVEL
POMO DE MUEBLE
PORCELAIN KNOB

A B
30 35



2048.6.37-003


0083532059043



12 x1



7



PUXADOR DE MÓVEL
POMO DE MUEBLE
PORCELAIN KNOB

A B
30 35




2048.7.37-003

0083532059227



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
PORCELAIN KNOB

A B
40 40




2049.40.37-003

3393992722119




12 x1




PUXADOR DE MÓVEL
 POMO DE MUEBLE
 PORCELAIN KNOB

A	B				
25	30		2055.25.37-003	0083532025819	12 x1
30	35		2055.30.37-003	0083532025949	12 x1
35	37		2055.35.37-003	0083532026083	12 x1




PUXADOR DE MÓVEL
 POMO DE MUEBLE
 PORCELAIN KNOB

A	B				
25	30		2055.25.71-003	0083532025789	12 x1
30	35		2055.30.71-003	0083532025901	12 x1
35	37		2055.35.71-003	0083532026052	12 x1




PUXADOR DE MÓVEL
 POMO DE MUEBLE
 PORCELAIN KNOB

A	B				
25	30		2055.25.72-003	0083532025727	12 x1
30	35		2055.30.72-003	0083532025840	12 x1
35	37		2055.35.72-003	0083532025994	12 x1




PUXADOR DE MÓVEL
 POMO DE MUEBLE
 PORCELAIN KNOB

A	B				
25	30		2055.25.73-003	0083532025758	12 x1
30	35		2055.30.73-003	0083532025871	12 x1
35	37		2055.35.73-003	0083532026021	12 x1




PUXADOR DE MÓVEL
 POMO DE MUEBLE
 PORCELAIN KNOB

A					
30		2056.30.37-003	3393992536105		12 x1
35		2056.35.37-003	3393992536136		12 x1




PUXADOR DE MÓVEL
 POMO DE MUEBLE
 PORCELAIN KNOB

A					
30		2057.30.37-003	3393992537928		12 x1




PUXADOR DE MÓVEL
 POMO DE MUEBLE
 PORCELAIN KNOB

A					
32		2063.32.37-003	3393992571076		12 x1




PUXADOR DE MÓVEL
POMO DE MUEBLE
PORCELAIN KNOB

A	B				
40			2064.40.37-003	3393992721846	12 x1




PUXADOR DE MÓVEL
POMO DE MUEBLE
PORCELAIN KNOB

A	B				
30	35		2065.69-003	0083532026984	12 x1
30	35		2065.70-003	0083532027011	12 x1
30	35		2065.94-003	0083532035252	12 x1




PUXADOR DE MÓVEL
POMO DE MUEBLE
PORCELAIN KNOB

A	B				
32	25		2066.32.61-003	0083532062869	12 x1
32	25		2066.32.62-003	0083532063248	12 x1
32	25		2066.32.63-003	0083532063194	12 x1
32	25		2066.32.69-003	0083532063118	12 x1
32	25		2066.32.70-003	0083532062883	12 x1
32	25		2066.32.94-003	0083532062876	12 x1




PUXADOR DE MÓVEL
POMO DE MUEBLE
PORCELAIN KNOB

A	B				
40			2067.40.40-003	3393992721914	12 x1




PUXADOR DE MÓVEL
POMO DE MUEBLE
PORCELAIN KNOB

A	B				
40	35		2068.40.37-003	3393992679888	12 x1
40	35		2068.40.39-003	3393992679864	12 x1
40	35		2068.40.62-003	3393992679857	12 x1
40	35		2068.40.68-003	3393992679840	12 x1
40	35		2068.40.69-003	3393999013968	12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
PORCELAIN KNOB

A	B				
34	28		2075.2-003	0083532033081	12 x1
34	28		2075.6-003	0083532033319	12 x1



PUXADOR DE MÓVEL
 POMO DE MUEBLE
 PORCELAIN KNOB

A B

25 30



2078.25.69-003

0083532033326



12 x1

30 40




2078.30.69-003

0083532033487



12 x1



PUXADOR DE MÓVEL
 POMO DE MUEBLE
 KNOB

A B

38 27




2806.40.38-003

3393999013890



10 x1



PUXADOR DE MÓVEL
 POMO DE MUEBLE
 KNOB

A B

38 27




2807.38.38-003

3393999013906



12 x1



PUXADOR DE MÓVEL
 POMO DE MUEBLE
 KNOB

A B

40 26




3047.40.26-003

3393992722010



12 x1



PUXADOR DE MÓVEL
 POMO DE MUEBLE
 KNOB

A B

40 26




3048.40.15-003

3393992722034



12 x1



PUXADOR DE MÓVEL
 POMO DE MUEBLE
 KNOB

A B

40 26




3049.36.37-003

3393992722225



10 x1



PUXADOR DE MÓVEL
 POMO DE MUEBLE
 PORCELAIN KNOB

A B

33 33




650.33.37-003

0083532033197



12 x1



PUXADOR DE MÓVEL
 POMO DE MUEBLE
 PORCELAIN KNOB

A B

33 33




650.33.38-003

0083532033302



12 x1




PUXADOR DE MÓVEL
POMO DE MUEBLE
PORCELAIN KNOB

A B
35 18

9602.35.17-003

3393999013722

12 x1




PUXADOR DE MÓVEL
POMO DE MUEBLE
PORCELAIN KNOB

A B
35 18

9602.35.37-003

3393999013715

12 x1




PUXADOR DE MÓVEL
POMO DE MUEBLE
PORCELAIN KNOB

A B
35 18

9602.35.38-003

3393999015177

12 x1




PUXADOR DE MÓVEL
POMO DE MUEBLE
PORCELAIN KNOB

A B
35 18

9602.35.40-003

3393999015160

12 x1




PUXADOR DE MÓVEL
POMO DE MUEBLE
PORCELAIN KNOB

A B
35 18

9602.35.49-003

3393999015191

12 x1




PUXADOR DE MÓVEL
POMO DE MUEBLE
PORCELAIN KNOB

A B
35 18

9623.37.40-003

3393999015214

12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A

96



1140.96.33-003

3393999039111

12 x1

96



1140.96.33-405

3393999040377

3 x5

128



1140.128.33-003

3393999039128

12 x1

128



1140.128.33-405

3393999553013

3 x5


160



1140.160.33-003

3393999039135

12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A


96



1281.96.16-003


3393992583635

12 x1




ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A
96  **1282.96.40-003** 3393992571250  12 x1




ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A
96  **1308.96.16-003** 0083532058589  12 x1
128  **1308.128.16-003** 0083532071151  12 x1




ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A
160  **1312.160.16-003** 0083532097120  12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A
96  **179.16-003** 0083532013779  12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A
96  **180.16-003** 0083532037133  12 x1




ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A
96  **181.16-003** 0083532037485  12 x1




ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A
96  **1857.96.33-003** 3393999039081  12 x1
128  **1857.128.33-003** 3393999039098  12 x1
160  **1857.160.33-003** 3393999039104  12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A
93  **374.16-003** 0083532095836  12 x1
93  **374.16-033** 4400000035150  24 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A
93




375.16-003

0083532015995



12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A
96



390.96.16-003

0083532070024



12 x1

128




390.128.16-003

0083532070482



12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
CUPPED HANDLE

A B C
113 30 100x25
140 30 133x25



412.96.16-003

0083532057629



12 x1

412.128.16-003

0083532057599



12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A
64



413.64.16-003

0083532059265



12 x1

96




413.96.16-003

0083532059449



12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A
96



420.96.16-003

3393992535740



12 x1

96



420.96.16-405

3393999654680



3 x5

128




420.128.16-003

3393992535788



12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A
90



424.105.16-003

0083532055243



12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A
64



570.64.16-003

0083532071762



12 x1

128




570.128.16-003

0083532071533



12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A
32



623.32.16-003

0083532059616



12 x1

64




623.64.16-003


0083532069790




12 x1


 ASA DE MÓVEL
 TIRADOR DE MUEBLE
 HANDLE


A	B				
96	170		625.16-003	0083532010044	12 x1


 ASA DE MÓVEL
 TIRADOR DE MUEBLE
 HANDLE


A					
32		626.32.16-003	0083532069509		12 x1
64		626.64.16-003	0083532069578		12 x1


 ASA DE MÓVEL
 TIRADOR DE MUEBLE
 HANDLE


A					
128		670.96.16-003	0083532049716		12 x1
128		670.128.16-003	0083532000939		12 x1


 ASA DE MÓVEL
 TIRADOR DE MUEBLE
 HANDLE


A	B				
64	12		672.64.33-003	0083532037195	12 x1
96	12		672.96.33-003	0083532037249	12 x1
96	12		672.96.33-405	3393999654772	3 x5
128	12		672.128.33-003	0083532037256	12 x1
160	12		672.160.33-003	0083532037287	12 x1


 ASA DE MÓVEL
 TIRADOR DE MUEBLE
 HANDLE


A					
128		763.128.16-003	0083532096208		12 x1
128		763.128.16-405	3393999654697		3 x5
96		763.96.16-003	0083532047323		12 x1


 ASA DE MÓVEL
 TIRADOR DE MUEBLE
 HANDLE


A					
64		765.64.16-003	0083532096239		12 x1


 ASA DE MÓVEL
 TIRADOR DE MUEBLE
 HANDLE

A					
96		766.96.16-003	0083532060087		12 x1



 ASA DE MÓVEL
 TIRADOR DE MUEBLE
 HANDLE

A	B				
128	8		767.128.16-003	0083532095980	12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A				
96		768.96.16-003	0083532060117	12 x1




ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A	B			
96	8		780.96.16-003	0083532085066 12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A				
96		782.96.16-003	0083532070857	12 x1
160		782.160.16-003	0083532073674	12 x1




ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A				
64		786.64.16-003	0083532076088	12 x1
96		786.96.16-003	0083532076385	12 x1
128		786.128.16-003	0083532077214	12 x1
192		786.192.16-003	0083532082188	6 x1




ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A				
32		788.32.16-003	0083532001745	12 x1
64		788.64.16-003	0083532092637	12 x1
96		788.96.16-003	0083532092934	12 x1




ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A				
96		796.96.16-003	0083532027592	12 x1
128		796.128.16-003	0083532027707	12 x1




ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A				
96		798.96.16-003	0083532019740	12 x1
128		798.128.16-003	0083532019658	12 x1




ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A				
96		870.96.16-003	0083532080047	12 x1
128		870.128.16-003	0083532013762	12 x1




ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A				
32		899.32.3-003	3393999015061	12 x1
64		899.64.3-003	3393999015054	12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A				
64		951.64.16-003	0083532034200	12 x1
96		951.96.16-003	0083532034255	12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A				
64		955.16-003	0083532097540	12 x1




ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A	B			
80	35		1300.18-003	0083532058770 12 x1




ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A	B			
35	35		1301.18-003	0083532058763 12 x1




ASA DE MÓVEL ENCASTRAR
TIRADOR DE MUEBLE ENCASTRAR
CUPPED HANDLE

A	B			
95x19	25x100		1302.18-003	0083532059647 12 x1




ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A				
96		1309.96.18-003	0083532069257	12 x1
128		1309.128.18-003	0083532069165	12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A				
96		1376.96.18-003	3393999039616	12 x1
128		1376.128.18-003	3393999039623	12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A
128-
160




1379.128-160.18-003

3393999039753



12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A
128




1392.128.18-003

0083532058640



12 x1



ASA DE MÓVEL ENCASTRAR
TIRADOR DE MUEBLE ENCASTRAR
CUPPED HANDLE

A B
96x30 110x40




1393.96.18-003

0083532058848



12 x1



ASA DE MÓVEL ENCASTRAR
TIRADOR DE MUEBLE ENCASTRAR
CUPPED HANDLE

A B
35 40




1394.40.18-003

0083532058824



12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A
64
96
96



1395.64.18-003

0083532069493



12 x1



1395.96.18-003

0083532058534



12 x1




1395.96.18-306

3393999018741



6 x6



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A
64




1399.64.18-003

3393999552481



12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A
96
128
160



316.96.18-003

3393999039760



6 x1



316.128.18-003

3393999039777



6 x1




316.160.18-003

3393999654000



6 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A
64-96
128-
160



415.64-96.18-003

0083532069820



12 x1




415.128-160.18-003

0083532058657




12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A				
160		416.160.18-003	0083532058688	6 x1
192		416.192.18-003	0083532058749	6 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A				
96		417.96.16-003	0083532059203	12 x1
128		417.128.16-003	0083532059210	12 x1




ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A				
32		418.32.18-003	3393999039708	12 x1




ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A				
128		419.128.16-003	0083532059586	12 x1




ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A				
160		421.160.18-003	0083532058664	6 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A				
96		423.96.18-003	0083532058602	12 x1
128		423.128.18-003	0083532058633	12 x1




ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A				
64		765.64.18-003	0083532062258	12 x1




ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A				
64		844.64.18-003	3393999039647	12 x1
96		844.96.18-003	3393999552498	12 x1
128		844.128.18-003	3393999039654	12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A
96  **954.96.18-003** 3393999552443  12 x1




ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A
96  **801.96.26-003** 0083532060131  12 x1
96  **801.96.26-306** 3393999552832  6 x6
128  **801.128.26-003** 0083532060124  12 x1




ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A
96  **802.96.26-003** 0083532060162  12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A
128  **1309.128.13-003** 0083532059401  12 x1




ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A
68  **1374.13-003** 3393999654932  12 x1
68  **1374.13-405** 3393999654789  3 x5




ASA DE MÓVEL ENCASTRAR
TIRADOR DE MUEBLE ENCASTRAR
CUPPED HANDLE

A
40  **1404.40.13-003** 3393999039593  12 x1




ASA DE MÓVEL ENCASTRAR
TIRADOR DE MUEBLE ENCASTRAR
CUPPED HANDLE

A B
35 40  **1405.40.13-003** 3393999039609  12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A
96  **180.13-003** 0083532037010  12 x1




ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A					
96		420.96.13-003	3393992535757		12 x1
96		420.96.13-405	3393999040414		3 x5
128		420.128.13-003	3393992535795		12 x1




ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

	0083532070932	x
--	---------------	---




ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A	B				
96	170		625.13-003	0083532010129	12 x1




ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A					
32		626.32.13-003	0083532070529		12 x1
64		626.64.13-003	0083532070642		12 x1




ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A					
96		670.96.13-003	0083532049341		12 x1
128		670.128.13-003	0083532000847		12 x1




ASA DE MÓVEL
TIRADOR DE MUEBLE
KNOB

A					
96		763.96.13-003	0083532047750		12 x1
128		763.128.13-003	0083532047552		12 x1




PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A	B				
30	19		763.30.13-003	0083532047651	12 x1




ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A					
96		782.96.13-003	0083532070826		12 x1




ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A				
64		786.64.13-003	0083532076057	12 x1
96		786.96.13-003	0083532076842	12 x1
128		786.128.13-003	0083532077184	12 x1
192		786.192.13-003	0083532078860	6 x1




ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A				
32		788.32.13-003	0083532001714	12 x1
64		788.64.13-003	0083532092514	12 x1
96		788.96.13-003	0083532092903	12 x1




ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A				
96		794.96.13-003	0083532053553	12 x1
128		794.128.13-003	0083532026991	12 x1




ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A				
96		798.96.13-003	0083532019719	12 x1
128		798.128.13-003	0083532019627	12 x1




ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A				
96		870.96.13-003	0083532080009	12 x1
128		870.128.13-003	0083532012574	12 x1




ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A				
64		951.64.13-003	0083532010327	12 x1
96		951.96.13-003	0083532010617	12 x1




ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A				
96		954.96.13-003	3393999552474	12 x1




ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE


A				
75		956.75.13-003	3393999039692	12 x1


 ASA DE MÓVEL
 TIRADOR DE MUEBLE
 HANDLE


A				
64		1180.64.2-003	0083532096468	12 x1
96		1180.96.2-003	0083532096482	12 x1


 ASA DE MÓVEL
 TIRADOR DE MUEBLE
 HANDLE


A				
70		1182.70.2-003	0083532095324	12 x1
90		1182.90.2-003	0083532095355	12 x1


 ASA DE MÓVEL
 TIRADOR DE MUEBLE
 HANDLE


A				
96		1183.96.12-003	0083532062449	12 x1


 ASA DE MÓVEL
 TIRADOR DE MUEBLE
 HANDLE


A	B			
64	7		140.64.12-003	0083532017159 12 x1
96	7		140.96.12-003	0083532017487 12 x1
128	7		140.128.12-003	3393992537430 12 x1


 ASA DE MÓVEL
 TIRADOR DE MUEBLE
 HANDLE


A				
96		142.2-003	0083532042472	12 x1


 ASA DE MÓVEL
 TIRADOR DE MUEBLE
 HANDLE


A				
96		180.12-003	0083532021279	12 x1


 ASA DE MÓVEL
 TIRADOR DE MUEBLE
 HANDLE

A				
96		181.12-003	0083532037225	12 x1



 ASA DE MÓVEL
 TIRADOR DE MUEBLE
 HANDLE

A				
105		183.105.2-003	0083532022955	12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A				
90		198.90.2-003	0083532023624	12 x1
110		198.110.2-003	0083532023556	12 x1




ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A	B	C				
91	64	10		213.64.2/5-003	0083532047897	12 x1
121	96	10		213.96.2/5-003	0083532048146	12 x1
154	128	10		213.128.2/5-003	0083532048269	12 x1




ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A				
96		214.100.12-003	0083532031773	12 x1




ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A				
64		231.64.12-003	0083532036969	12 x1
96		231.96.12-003	0083532037119	12 x1




ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A				
64		255.64.2-003	0083532013328	12 x1
96		255.96.2-003	0083532013380	12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A				
64		353.64.12-003	0083532098370	12 x1
96		353.96.12-003	0083532098349	12 x1




ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A				
93		374.12-003	0083532015766	12 x1




ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A				
93		375.12-003	0083532015926	12 x1


 ASA DE MÓVEL
 TIRADOR DE MUEBLE
 HANDLE

A					
102		380.90.2-003	0083532051238		12 x1
122		380.115.2-003	0083532051184		12 x1


 ASA DE MÓVEL
 TIRADOR DE MUEBLE
 HANDLE


A					
96		420.96.12-003	3393992535726		12 x1
96		420.96.12-405	3393999654703		3 x5
128		420.128.12-003	3393992535764		12 x1


 ASA DE MÓVEL
 TIRADOR DE MUEBLE
 HANDLE


A	B				
50	79		502.2-003	0083532065914	12 x1


 ASA DE MÓVEL
 TIRADOR DE MUEBLE
 HANDLE


A	B				
45	60		503.2-003	0083532066010	12 x1


 ASA DE MÓVEL
 TIRADOR DE MUEBLE
 HANDLE


A					
96		550.2-003	0083532099377		12 x1


 ASA DE MÓVEL
 TIRADOR DE MUEBLE
 HANDLE


A					
80		563.80.12-003	0083532070901		12 x1


 ASA DE MÓVEL
 TIRADOR DE MUEBLE
 HANDLE

A					
103		591.103.2-003	0083532083918		12 x1
128		591.128.2-003	0083532083956		12 x1


 ASA DE MÓVEL
 TIRADOR DE MUEBLE
 HANDLE

A					
155		592.2-003	0083532084083		12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A
96 B
170

625.12-003

0083532042496



12 x1



ASA DE MÓVEL LOUIS XVI
TIRADOR DE MUEBLE LOUIS XVI
HANDLE LOUIS XVI

A
96




754.96.2-003

0083532056585



12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A
96




762.96.2-003

0083532014042



12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A
64




765.64.12-003

0083532096222



12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A
96



782.96.12-003

0083532087923



12 x1

160




782.160.12-003

0083532071069



12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A
64



786.64.12-003

0083532075999



12 x1

96



786.96.12-003

0083532076811



12 x1

128



786.128.12-003

0083532077153



12 x1




786.192.12-003

0083532078761



6 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A
96



787.96.12-003

3393999553273



12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A
32



788.32.12-003

0083532084731



12 x1

64



788.64.12-003

0083532092484



12 x1

96




788.96.12-003

0083532092699




12 x1


 ASA DE MÓVEL
 TIRADOR DE MUEBLE
 HANDLE


A				
96		798.96.12-003	0083532027769	12 x1
128		798.128.12-003	0083532019597	12 x1


 ASA DE MÓVEL
 TIRADOR DE MUEBLE
 HANDLE


A				
32		899.32.2-003	3393999015023	12 x1
64		899.64.2-003	3393999015016	12 x1


 ASA DE MÓVEL
 TIRADOR DE MUEBLE
 HANDLE


A				
110		942.2-003	0083532063750	12 x1


 ASA DE MÓVEL
 TIRADOR DE MUEBLE
 HANDLE


A				
64		951.64.12-003	0083532010280	12 x1
96		951.96.12-003	0083532010341	12 x1


 ASA DE MÓVEL
 TIRADOR DE MUEBLE
 HANDLE


A				
64		955.15-003	0083532097519	12 x1


 ASA DE MÓVEL
 TIRADOR DE MUEBLE
 HANDLE


A				
64		1180.64.1-003	0083532096444	12 x1
96		1180.96.1-003	0083532096475	12 x1


 ASA DE MÓVEL
 TIRADOR DE MUEBLE
 HANDLE

A				
70		1182.70.1-003	0083532095317	12 x1
90		1182.90.1-003	0083532095331	12 x1


 ASA DE MÓVEL
 TIRADOR DE MUEBLE
 HANDLE

A				
96		1183.96.11-003	0083532062265	10 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A
64




143.64.1-003

0083532075098



12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A

90



198.90.1-003

0083532023587



12 x1

110



198.110.1-003

0083532023525



12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A

64



231.64.11-003

0083532036938



12 x1

96



231.96.11-003

0083532037089



12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A

64



255.64.1-003

0083532013410



12 x1

96




255.96.1-003

0083532013434



12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A

64



353.64.11-003

0083532098387



12 x1

96




353.96.11-003

0083532098356



12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A

96



726.96.11-003

0083532088586



12 x1

128



726.128.11-003

0083532088593



12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE DIRECTOIRE

A

96




756.96.1-003

0083532056721



12 x1



ASA DE MÓVEL LOUIS XVI
TIRADOR DE MUEBLE LOUIS XV
HANDLE LOUIS XV

A

155




761.96.1-003

0083532057117



12 x1


 ASA DE MÓVEL
 TIRADOR DE MUEBLE
 HANDLE

A


96

**762.96.1-003**

0083532014059



12 x1


 ASA DE MÓVEL
 TIRADOR DE MUEBLE
 HANDLE

A


64

**765.64.11-003**

0083532096215



12 x1


 ASA DE MÓVEL
 TIRADOR DE MUEBLE
 HANDLE

A

64

**772.64.11-003**

0083532084311



12 x1


96

**772.96.11-003**

0083532068441



12 x1


 ASA DE MÓVEL
 TIRADOR DE MUEBLE
 HANDLE

A


96

**775.11-003**

0083532084465



12 x1


 ASA DE MÓVEL
 TIRADOR DE MUEBLE
 HANDLE

A

96

**787.96.11-003**

0083532071113



12 x1

96

**787.96.11-405**

3393999654727



3 x5


 ASA DE MÓVEL
 TIRADOR DE MUEBLE
 HANDLE

A

96

**789.96.11-003**

0083532088760



12 x1


 ASA DE MÓVEL
 TIRADOR DE MUEBLE
 HANDLE

A

64

**951.64.11-003**

0083532096352



12 x1


96

**951.96.11-003**

0083532096413



12 x1


 ASA DE MÓVEL
 TIRADOR DE MUEBLE
 HANDLE

A


64

**965.11-003**

0083532053096



12 x1



ASA DE MALETA
TIRADOR DE MALETA
SUITCASE HANDLE

A B
50 160




10026.160.17-009

3393999133475



6 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A

96



420.96.17-003

3393992535733



12 x1

128




420.128.17-003

3393992535771



12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A

96




570.96.17-003

0083532072080



12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A

64




570.64.37-003

0083532071878



12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A

128




649.128.31/19-003

0083532022184



12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A

96




786.96.17-003

0083532076484



12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A

96



794.96.17-003

0083532001646



12 x1

128




794.128.17-003

0083532027622



12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A

96



794.96.37-003

0083532026908



12 x1

128




794.128.37-003


0083532027479




12 x1


 ASA DE MÓVEL
 TIRADOR DE MUEBLE
 HANDLE


A				
96		798.96.17-003	0083532019566	12 x1
128		798.128.17-003	0083532019689	12 x1


 ASA DE MÓVEL
 TIRADOR DE MUEBLE
 HANDLE


A				
32		899.32.7-003	3393999014972	12 x1
64		899.64.7-003	3393999014965	12 x1


 ASA DE MÓVEL
 TIRADOR DE MUEBLE
 PORCELAIN HANDLE


A				
96		1650.1.16-003	0083532091234	12 x1
96		1650.1.16-405	3393999040476	3 x5


 ASA DE MÓVEL
 TIRADOR DE MUEBLE
 PORCELAIN HANDLE


A				
96		1650.2.16-003	0083532091241	12 x1


 ASA DE MÓVEL
 TIRADOR DE MUEBLE
 PORCELAIN HANDLE


A				
96		1650.3.16-003	0083532091258	12 x1


 ASA DE MÓVEL
 TIRADOR DE MUEBLE
 PORCELAIN HANDLE

A	B	C		
97	27	25		1803.69-003 3393992652614 6 x1


 ASA DE MÓVEL
 TIRADOR DE MUEBLE
 PORCELAIN HANDLE

A				
128		650.128.37-003	0083532033203	12 x1


 ASA DE MÓVEL
 TIRADOR DE MUEBLE
 PORCELAIN HANDLE

A				
128		650.128.38-003	0083532033227	12 x1



ENTRADA DE CHAVE
BOCALLAVE
ESCUTCHEON

A
30



563.R.16-003

0083532070000



12 x1



ENTRADA DE CHAVE
BOCALLAVE
ESCUTCHEON

A
30



563.R.13-003

0083532069943



12 x1



ENTRADA DE CHAVE
BOCALLAVE
ESCUTCHEON

A
17

B
40



1185.2-003

0083532096345



12 x1



ENTRADA DE CHAVE
BOCALLAVE
ESCUTCHEON

A
16

B
68



1186.2-003

0083532096376



12 x1



ENTRADA DE CHAVE
BOCALLAVE
ESCUTCHEON

A
20

B
35



1187.2-003

0083532095393



12 x1



ENTRADA DE CHAVE
BOCALLAVE
ROUND ESCUTCHEON

A
27



1188.2-003

0083532096406



12 x1



ENTRADA DE CHAVE
BOCALLAVE
ESCUTCHEON

A
20

B
40



1189.2-003

0083532096437



12 x1



BERLOQUE
BERLOQUE
ROSE WITH LOOSE PULLER

A
50



1195.2-003

0083532096321



12 x1



FICHA PARA MÓVEL
 FICHA PARA MUEBLE
 FURNITURE LIFT-OFF HINGE, ORNAMENTED TOP

A	B				
8	100		197.100.2-003	0083532023310	12 x1
8	100		197.100.2-009	3393999117840	6 x2
12	130		197.130.2-003	0083532023372	12 x1
12	130		197.130.2-009	3393999117857	6 x2
12	170		197.170.2-003	0083532023433	12 x1



ENTRADA DE CHAVE
 BOCALLAVE
 ESCUTCHEON

A	B				
22	35		209.0.15-003	0083532028469	12 x1



ENTRADA DE CHAVE
 BOCALLAVE
 ESCUTCHEON

A	B				
29	50		215.12-003	0083532032305	12 x1



ENTRADA DE CHAVE
 BOCALLAVE
 ROUND ESCUTCHEON

A					
34		231.12-003	0083532036471		12 x1



ENTRADA DE CHAVE
 BOCALLAVE
 ESCUTCHEON

A	B				
16	36		256.2-003	0083532013564	12 x1



ANILHA
 ANILLA
 RING

A					
35		353.35.12-003	0083532098417		12 x1




CHAVE DECORATIVA
 LLAVE DECORATIVA
 ORNAMENTED KEY

A					
75		353.12-003	0083532046098		12 x1



ENTRADA DE CHAVE
 BOCALLAVE
 ESCUTCHEON

A	B				
30	25		353.30.12-003	0083532051320	12 x1



PORTA-ETIQUETA
PUERTA-ETIQUETA
LABEL HOLDER

A	B	C
60	20	45x8
80	30	60x15



373.60.2-003

0083532050545



12 x4

373.80.2-003

0083532050583



12 x4



ANILHA COM ROSETA
ANILLA CON ROSETA
RING ON ROSE

A

46




490.15-003

3393999551163



12 x1



CANTO DE MESA
ESQUINA DE MESA
TABLE CORNER PROTECTOR

A	B	C
54	54	20



504.2-003

0083532066119



12 x1



BERLOQUE
BERLOQUE
ROSE WITH LOOSE PULLER

A

50



542.2-003

0083532059623



12 x1



ANILHA
ANILLA
RING

A

33



543.2-003

0083532059654



12 x1



ENTRADA DE CHAVE
BOCALLAVE
ESCUTCHEON

A

30



563.R.12-003

0083532069912



12 x1



ENTRADA DE CHAVE
BOCALLAVE
ROUND ESCUTCHEON

A

31



730.2-003

0083532082690



12 x1



CHAVE LOUIS XVI
LLAVE LOUIS XVI
KEY LOUIS XVI

A

77

B

23

35



758.2-003

0083532056967



12 x1



758.23X35.2-003

0083532056912



12 x1



ANILHA LOUIS XVI
 ANILLA LOUIS XVI
 RING WITH LOOSE PULLER LOUIS XVI

A

47



759.2-003

0083532056981



12 x1



ENTRADA DE CHAVE
 BOCALLAVE
 ESCUTCHEON

A

17

B

40



1185.1-003

0083532096338



12 x1



ENTRADA DE CHAVE
 BOCALLAVE
 ESCUTCHEON

A

16

B

68



1186.1-003

0083532096369



12 x1



ENTRADA DE CHAVE
 BOCALLAVE
 ESCUTCHEON

A

20

B

35



1187.1-003

0083532096390



12 x1



ENTRADA DE CHAVE
 BOCALLAVE
 ROUND ESCUTCHEON

A

27



1188.1-003

0083532095409



12 x1



ENTRADA DE CHAVE
 BOCALLAVE
 ESCUTCHEON

A

20

B

40



1189.1-003

0083532096420



12 x1



BERLOQUE
 BERLOQUE
 ROSE WITH LOOSE PULLER

A

50



1195.1-003

0083532096314



12 x1



BERLOQUE
 BERLOQUE
 ROSE WITH LOOSE PULLER

A

70



191.1-003

0083532023242



12 x1



FICHA PARA MÓVEL
FICHA PARA MUEBLE
FURNITURE LIFT-OFF HINGE, ORNAMENTED TOP

A	B				
8	100	197.100.1-003	0083532023273		12 x1
8	100	197.100.1-009	3393999117871		6 x2
12	130	197.130.1-003	0083532023341		12 x1
12	130	197.130.1-009	3393999117888		6 x2
		197.170.1-003	0083532023402		12 x1



ENTRADA DE CHAVE
BOCALLAVE
ESCUTCHEON

A	B				
15	135	199V.135.1-003	0083532023716		12 x1
15	180	199V.180.1-003	0083532023785		12 x1



ENTRADA DE CHAVE
BOCALLAVE
ESCUTCHEON

A	B				
22	35	209.0.11-003	0083532028438		12 x1



ENTRADA DE CHAVE
BOCALLAVE
ESCUTCHEON

A	B				
29	50	215.11-003	0083532032213		12 x1




ENTRADA DE CHAVE
BOCALLAVE
ROUND ESCUTCHEON

A					
34		231.11-003	0083532036440		12 x1



ENTRADA DE CHAVE
BOCALLAVE
ESCUTCHEON

A	B				
16	36	256.1-003	0083532013953		12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A	B				
30	30	337.11-003	0083532072141		12 x1



ENTRADA DE CHAVE
BOCALLAVE
ESCUTCHEON

A B
185 20



339.11-003

0083532047682



12 x1



ANILHA
ANILLA
RING

A

35



353.35.11-003

0083532022139



12 x1



CHAVE DECORATIVA
LLAVE DECORATIVA
ORNAMENTED KEY

A

75



353.11-003

0083532051931



12 x1



ENTRADA DE CHAVE
BOCALLAVE
ESCUTCHEON

A B
30 25



353.30.11-003

0083532098424



12 x1



ANILHA COM ROSETA
ANILLA CON ROSETA
RING ON ROSE

A

40




490.11-003

0083532065259



12 x1



BERLOQUE
BERLOQUE
ROSE WITH LOOSE PULLER

A

50



542.1-003

0083532059593



12 x1



ANILHA
ANILLA
RING

A

33



543.1-003

0083532059685



12 x1



ENTRADA DE CHAVE
BOCALLAVE
ESCUTCHEON

A

30



563.R.11-003

0083532069882



12 x1



CHAVE LOUIS XVI
LLAVE LOUIS XVI
KEY LOUIS XVI

A

60



61.11-003

0083532071274



12 x1



CHAVE DECORATIVA
LLAVE DECORATIVA
ORNAMENTED KEY

A

70



63.11-003

0083532071335



12 x1



ENTRADA DE CHAVE
BOCALLAVE
ESCUTCHEON

A

30



689.1-003

0083532078631



12 x1



ENTRADA DE CHAVE
BOCALLAVE
ROUND ESCUTCHEON

A

31



730.1-003

0083532082669



12 x1



BERLOQUE
BERLOQUE
ROSE WITH LOOSE PULLER DIRECTOIRE

A

73



756.20X73.1-003

0083532056752



12 x1



ENTRADA DE CHAVE
BOCALLAVE
ESCUTCHEON DIRECTOIRE

A

25

B

38



756.25X38.1-003

0083532056738



12 x1



CHAVE DECORATIVA
LLAVE DECORATIVA
KEY DIRECTOIRE

A

77



757.1-003

0083532056813



12 x1



CHAVE LOUIS XVI
LLAVE LOUIS XVI
KEY LOUIS XVI

A

77

B

23



758.1-003

0083532056936



12 x1

23

35



758.23X35.1-003

0083532056868



12 x1



ANILHA LOUIS XVI
ANILLA LOUIS XVI
RING WITH LOOSE PULLER LOUIS XVI

A

47




759.1-003

0083532056974



12 x1



CHAVE LOUIS XVI
LLAVE LOUIS XVI
KEY LOUIS XV

A

33

B

58



760.33X58.1-003

0083532057056



12 x1



CHAVE LOUIS XVI
LLAVE LOUIS XVI
KEY LOUIS XV

A

60



760.1-003

0083532056998



12 x1



ENTRADA DE CHAVE LOUIS XVI
BOCALLAVE LOUIS XVI
ESCUTCHEON LOUIS XV

A

30

B

61




761.30X61.1-003

0083532057131



12 x1



DOBRADIÇA PARA MÓVEL
BISAGRA PARA MUEBLE
HINGE FOR FURNITURE

A

10

B

60




769.11-003

0083532083857



12 x1



ASA DE MÓVEL
ASA DE MUEBLE
HANDLE

A

32

B

52



773.11-003

0083532084380



12 x1



ENTRADA DE CHAVE + CABEÇA DE CHAVE
BOCALLAVE + CABEZA DE LLAVE
ESCUTCHEON + KEY COVER

A

32

B

33



774.11-003

0083532084427



12 x1



ENTRADA DE CHAVE
BOCALLAVE
ESCUTCHEON

A B
22 139



776.11-003

0083532084496



12 x1



ENTRADA DE CHAVE
BOCALLAVE
ESCUTCHEON

A B
30 36



778.11-003

0083532034408



12 x1



ENTRADA DE CHAVE + CABEÇA DE CHAVE
BOCALLAVE + CABEZA DE LLAVE
ESCUTCHEON + KEY COVER

A B
32 33



783.11-003

0083532072486



12 x1



ENTRADA DE CHAVE
BOCALLAVE
ESCUTCHEON

A B
30 60




785.11-003

0083532075524



12 x1



PORTA-ETIQUETAS
PUERTA-ETIQUETAS
PLASTIC LABEL HOLDER

A B
93 28



372.17-009

3393999133321



12 x4


 PUXADOR DE MÓVEL
 POMO DE MUEBLE
 KNOB


 A B C
 55 22 32

1350.14-003

3393992645784



12 x1


 PUXADOR DE MÓVEL
 POMO DE MUEBLE
 KNOB


 A B
 38 57

1351.14-003

3393992645791



12 x1


 PUXADOR DE MÓVEL
 POMO DE MUEBLE
 KNOB


 A B
 38 34

1372.14-003

3393992645777



12 x1


 PUXADOR DE MÓVEL
 POMO DE MUEBLE
 KNOB

A

30


1785.30.14-003

3393992666383



12 x1


1785.35.14-003

3393992667458



12 x1


 PUXADOR DE MÓVEL
 POMO DE MUEBLE
 KNOB


 A B C
 48 19 36

678.14-003

3393999669158



12 x1


 PUXADOR DE MÓVEL
 POMO DE MUEBLE
 KNOB


 A B
 32 25

679.14-003

3393999564996



12 x1


 PUXADOR DE MÓVEL
 POMO DE MUEBLE
 KNOB


 A B
 33 27

680.14-003

3393999669202



12 x1


 PUXADOR DE MÓVEL
 POMO DE MUEBLE
 KNOB


 A B
 38 31

683.14-003

3393999565078



12 x1




PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
36 28

684.14-003

3393999565092

12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B

35 30

35 30

784.35.14-003


3393992667427

12 x1

784.35.14-406

3393999040438

3 x6



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB


A B C

45 60 18

1290.17-003

3393992583505

12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB


A B C

30 52 18

1292.17-003

3393992583529

12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB


A B

32 25

679.17-003

3393999565009

12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB


A B

33 27

680.17-003

3393999565030

12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB


A B

38 31

683.17-003

3393999565375

12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B

25 20

25 20

122.25.19-003


0083532072981

12 x1


122.25.19-406

3393999040445


3 x6


 PUXADOR DE MÓVEL
 POMO DE MUEBLE
 KNOB


A	B				
35	20		336.19-003	0083532071984	12 x1


 PUXADOR DE MÓVEL
 POMO DE MUEBLE
 KNOB


A	B				
30	29		770.19-003	0083532075517	12 x1


 PUXADOR DE MÓVEL
 POMO DE MUEBLE
 KNOB


A	B				
30	21		771.30.19-003	0083532073353	12 x1
30	21		771.30.19-406	3393999654758	3 x6
35	21		771.35.19-003	0083532088661	12 x1


 PUXADOR DE MÓVEL
 POMO DE MUEBLE
 KNOB

A	B				
25	25		779.25.19-003	0083532073803	12 x1


 PUXADOR DE MÓVEL
 POMO DE MUEBLE
 KNOB

A	B				
30	25		781.30.19-003	0083532073940	12 x1


 PUXADOR DE MÓVEL COM ROSETA
 POMO DE MUEBLE CON ROSETA
 KNOB + ROSE

A	B				
30	107		966.19-003	0083532075616	12 x1


 PUXADOR DE MÓVEL
 POMO DE MUEBLE
 KNOB

A					
30		1134.30.20-003	3393999040339	12 x1	


 PUXADOR DE MÓVEL
 POMO DE MUEBLE
 KNOB

A	B	C			
48	20	35		134.48.20-003	3393999040346 12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B C
55 22 32




1350.20-003

3393992602800



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
38 57





1351.20-003

3393992617958



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
45 27



1366.20-003

3393992618757



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
30 13



1370.20-003

3393992618870



12 x1

30 13




1370.20-406

3393999040421



3 x6



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
38 34




1372.20-003

3393992617972



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
25 22



1373.25.20-003

3393992618016



12 x1

35 30




1373.35.20-003

3393992618054



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
50 15




1381.13-003

3393992619143



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
30 20




1406.32.20-003

3393992676528



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
45 17




1623.20-003

3393992549952



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
56 17




1624.20-003

3393992549983



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A
30




3503.30.20-003

3393999039425



6 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B C
48 19 36




678.20-003

3393999669165



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
32 25




679.20-003

3393999565016



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
33 27




680.20-003

3393999565023



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
38 31




683.20-003

3393999565085



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
36 28





684.20-003

3393999565108




12 x1




PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

899.20.7-003 3393999014989 12 x1




PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

1365.22-003 3393992618719 12 x1




PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

1766.30.22-003 3393992539908 12 x1
1766.35.22-003 3393992539939 12 x1




PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

1294.39-003 3393992583543 12 x1




PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

1343.17-003 3393992602152 12 x1




PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

1343.39-003 3393992602138 12 x1




PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

1345.17-003 3393992602169 12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

1345.39-003 3393992602145 12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B C
32 32 22




1346.40-003

3393992601971



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B C
38 38 28




1347.39-003

3393992601759



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B C
42 30 28




1348.17-003

3393992601988



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
26 19




1386.20-003

3393992618498



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
26 19




1389.20-003

3393992618559



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
38 35




2801.35.39/40-003

3393999013937



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
38 35




2802.35.39-003

3393999013920



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
38 35




2803.35.40-003

3393999013913



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
38 35




2804.35.20-003

3393999013944



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
38 35




2805.35.64-003

3393999013951



12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A
96



1167.96.14-003

3393992645845



12 x1

128




1167.128.14-003

3393992645869



12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A
96



1357.96.14-003

3393992645807



12 x1

160




1357.160.14-003

3393992645821



12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A
82




682.14-003

3393999565047



12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A
87




690.14-003

3393999565115



12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A
90




958.90.14-003

3393992666260



12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A
115




609.17-003

0083532073810



12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A

82




682.17-003

3393999565061



12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A

87




690.17-003

3393999565139



12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A

78




957.78.17-003

3393999040315



12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A

96



726.96.19-003

0083532088609



12 x1

128




726.128.19-003

0083532088616



12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A

64




765.64.19-003

0083532087848



12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A

96




789.96.19-003

0083532088821



12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A

100



1163.100.20-003

3393992538444



12 x1

120




1163.120.20-003

3393992538451



12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A

96




1165.20-003

3393992538437




12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A				
96		1167.96.20-003	3393992645838	12 x1
128		1167.128.20-003	3393992645852	12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A				
96		1357.96.20-003	3393992602787	12 x1
160		1357.160.20-003	3393992645814	12 x1




ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A				
96		1377.20-003	3393992618092	12 x1




ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A				
82		682.20-003	3393999565054	12 x1




ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A				
87		690.20-003	3393999565122	12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A				
78		957.78.20-003	3393999040322	12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A				
50		1776.50.22-003	0083532037218	12 x1



ENTRADA DE CHAVE
BOCALLAVE
ESCUTCHEON

A	B			
25	78		1784.20-003	0083532045039 12 x1



ENTRADA DE CHAVE
BOCALLAVE
ESCUTCHEON

A B
25 78



1784.22-003

0083532044971



12 x1



ENTRADA DE CHAVE
BOCALLAVE
ESCUTCHEON

A

30



563.R.19-003

0083532073292



12 x1



ENTRADA DE CHAVE
BOCALLAVE
ESCUTCHEON

A B
16 36




256.19-003

0083532071571



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
30 30



337.19-003

0083532072325



12 x1



CHAVE LOUIS XVI
LLAVE LOUIS XVI
KEY LOUIS XVI

A

60



61.19-003

0083532071304



12 x1



CHAVE DECORATIVA
LLAVE DECORATIVA
ORNAMENTED KEY

A

70



63.19-003

0083532071366



12 x1



ENTRADA DE CHAVE + CABEÇA DE CHAVE
BOCALLAVE + CABEZA DE LLAVE
ESCUTCHEON + KEY COVER

A B
32 33



774.19-003

0083532072424



12 x1



ENTRADA DE CHAVE
BOCALLAVE
ESCUTCHEON

A B
30 36



778.19-003

0083532097335



12 x1



ENTRADA DE CHAVE+ CABEÇA DE CHAVE
BOCALLAVE+ CABEZA DE LLAVE
ESCUTCHEON + KEY COVER

A B
32 33

783.19-003 0083532072554 12 x1



ENTRADA DE CHAVE
BOCALLAVE
ESCUTCHEON

A

110

110

1786.20GD-003 0083532019634 12 x2

1786.22GD-003 0083532019696 12 x2

Gauche Links Droite Rechts



ENTRADA DE CHAVE
BOCALLAVE
ESCUTCHEON

A

160

160

1789.20GD-003 0083532019757 12 x2

1789.22GD-003 0083532019863 12 x2

Gauche Links Droite Rechts



ENTRADA DE CHAVE
BOCALLAVE
ESCUTCHEON

A

195

1791.20GD-003 0083532029022 12 x2

Gauche Links Droite Rechts



ENTRADA DE CHAVE
BOCALLAVE
ESCUTCHEON

A

80

614.17-003 0083532075890 12 x1




ANILHA
ANILLA
RING

A


80

620.35.17-003 0083532076682 12 x1




PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A	B				
30	35		1070.38-003	0083532063897	12 x1




PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A	B				
35	35		1071.38-003	0083532063910	12 x1




PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A	B				
40	30		1072.48-003	0083532064030	12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A	B				
35	30		1073.39-003	0083532064092	12 x1




PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A	B				
42	37		1349.40-003	3393992722461	12 x1




PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A					
30		1384.48-003	0083532063811		12 x1
30		1384.66-003	0083532063828		10 x1
30		1384.69-003	0083532063842		12 x1
30		1384.94-003	0083532063859		12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A	B				
45	55		1449.41-003	3393992706522	12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A	B				
45	50		1451.94-003	3393992706539	12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A

45




1452.66-003

3393992706546



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A

40



1453.66-003

3393992706553



12 x1

40



1453.68-003

3393992706577



12 x1

40




1453.94-003

3393992706560



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A

45

B

25

C

27




1511.69-003

3393992602374



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A

60

B

33

C

23




1520.69-003

3393992619693



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A

43

B

35

C

27




1515.69-003

3393992602381



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A

40

B

28

C

27




1521.69-003

3393992619709



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A

33

B

50

C

27




1518.69-003

3393992619679



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A

51

B

57

C

23




1519.69-003

3393992619686



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B C
45 45 33




1512.40-003

3393992602398



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B C
40 57 30




1517.40-003

3393992619662



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B C
60 50 30




1522.40-003

0083532067697



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B C
45 50 30




1523.40-003

3393992652997



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
WOODEN KNOB - VARNISHED

A B
53 42




1525.70-003

3393992602039



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B C
30 65 30




1530.48-003

0083532067512



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B C
40 50 30




1531.48-003

0083532067536



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B C
35 50 30




1532.48-003

3393992652966



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A	B	C
45	40	30





1534.48-003

0083532067673



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A	B
---	---

47	30
----	----

47	30
----	----



1630.68-003

3393992558367



12 x1



1630.69-003

3393992561794



12 x1




1630.70-003

3393992560537



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A	B	C
---	---	---

50	50	20
----	----	----

50	50	20
----	----	----



1653.16-003

3393992571700



12 x1



1653.69-003

3393992571694



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A

35

35



1670.37-003

3393992617736



12 x1




1670.69-003

3393992617712



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A	B
---	---

50	55
----	----




1684.38-003

3393992586629



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A	B
---	---

50	36
----	----




1685-003

3393992601995



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A	B
---	---

40	50
----	----

40	50
----	----

40	50
----	----



1686.62-003

0083532075661



12 x1



1686.66-003

0083532063705



12 x1




1686.94-003

0083532063767



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A	B
---	---

35	35
----	----



1688.69-003

0083532063446



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A

35



1689.69-003

0083532063385



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A

35



1690.38-003

0083532063286



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A

35



1691.37-003

0083532063293



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A

30

B

40



1692.68-003

0083532063309



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A

25

B

35



1694.69-003

0083532063354



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A

25

B

42



1695.66-003

0083532019849



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A

35

B

25



1696.68-003

0083532063491



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A

35

B

35



1697.68-003

0083532063477



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
35 25



1698.70-003

0083532063484



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A

34



1699.37-003

0083532064689



12 x1

34



1699.62-003

0083532064641



12 x1

34



1699.66-003

0083532064634



12 x1

34



1699.70-003

0083532064610



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B

43 23



1700.61-003

3393992656063



12 x1

43 23



1700.66-003

3393992656094



12 x1

43 23



1700.70-003

3393992656070



12 x1

43 23




1700.94-003

3393992656087



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
PORCELAIN KNOB

A B

32 35



1710.32.61-003

3393992563804



12 x1

32 35



1710.32.61-406

3393999040483



3 x6

32 35



1710.32.69-003

3393992563811



12 x1

32 35



1710.32.69-406

3393999552825



3 x6



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B

60 45




1742.68-003

3393992586988



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B

32 34




1743.70-003

3393992586582



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B

32 34




1744.37-003

3393992586605



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A	B	C				
50	28	28		1746.40-003	3393992586919	12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A	B					
35	30		1748.61-003	0083532063507		12 x1




PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A	B					
35	30		1751.66-003	3393999554485		12 x1
35	30		1751.68-003	0083532063538		12 x1




PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A	B				
25	55		1755.70-003	3393992601810	 12 x1




PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A	B	C				
42	28	30		1761.40-003	3393992602053	12 x1





PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB



A	B	C				
40	32	30		1762.40-003	3393992602084	12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB


A	B					
39	39		1805.17-003	3393992652348		12 x1
39	39		1805.37-003	3393992652355		12 x1
39	39		1805.62-003	3393992652317		12 x1
39	39		1805.66-003	3393992652324		12 x1
39	39		1805.70-003	3393992652331		12 x1
39	39		1805.95-003	3393999001392		12 x1






PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A	B				
25			1813.1.17-003	3393992652492	12 x1
25			1813.2.17-003	3393992652508	12 x1
25			1813.3.17-003	3393992652515	12 x1
25			1813.4.37-003	3393992652522	12 x1
25			1813.5.37-003	3393992652539	12 x1
25			1813.6.37-003	3393992652546	12 x1




PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A	B				
28	25		651.69-003	0083532059746	12 x1
28	25		651.94-003	0083532059777	12 x1




PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A	B				
25	26		652.69-003	0083532059807	12 x1
25	26		652.94-003	0083532059838	12 x1




PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A	B				
25	26		653.69-003	0083532059890	12 x1
25	26		653.94-003	0083532059944	12 x1




PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A	B				
25	25		654.69-003	0083532059968	12 x1
25	25		654.94-003	0083532059975	12 x1




PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A	B				
20	33		655.69-003	0083532059982	12 x1
20	33		655.94-003	0083532059999	12 x1




PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A	B				
33	27		658.69-003	0083532079157	12 x1
33	27		658.94-003	0083532079164	12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB 'STARFISH'

A	B					
52	30		661.61-003	0083532005620		12 x1
52	30		661.69-003	0083532005637		12 x1
52	30		661.95-003	0083532060018		12 x1




PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A	B					
47	28		663.61-003	0083532005712		12 x1
47	28		663.69-003	0083532050675		12 x1
47	28		663.95-003	0083532060025		12 x1




PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A	B					
44	26		665.61-003	0083532006627		12 x1
44	26		665.69-003	0083532007280		12 x1
44	26		665.95-003	0083532060032		12 x1




PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A	B					
38	25		667.61-003	0083532007877		12 x1
38	25		667.69-003	0083532007884		12 x1
38	25		667.95-003	0083532060049		12 x1




PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A	B					
46	25		669.61-003	0083532008720		12 x1
46	25		669.69-003	0083532009628		12 x1
46	25		669.95-003	0083532060070		12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A	B					
36	28		700.38-003	0083532079171		12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A	B					
36	36		701.38-003	0083532079188		12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
40 25



702.38-003

0083532079409



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
30 33



703.38-003

0083532079423



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
35 31




704.38-003

0083532079485



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
29 29



705.38-003

0083532079508



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
35 30



715.38-003

3393999554492



12 x1

35 30




715.66-003

0083532063880



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A
40



8595.1.13-003

3393992655080



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
36 57



9603.63-003

3393999013739



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
48 40




9606.37-003

3393999013845



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
44 50




9607.37-003

3393999013852



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
55 65




9611.62-003

3393999013746



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
48 57




9613.37-003

3393999013760



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
49 42




9614.40-003

3393999013777



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
38 25




9618.1.42-003

3393999015108



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
38 25




9618.2.42-003

3393999015115



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
37 25




9620.40.42-003

3393999015122



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
37 28




9622.36.42-003

3393999015146



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
37 28




9622.36.69-003

3393999015153



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
50 22




9624.50.16-003

3393999015221



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
50 22




9624.50.61-003

3393999015238



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
50 22




9624.50.94-003

3393999015245



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
54 17




9625.53.17-003

3393999015269



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
54 17




9625.53.40-003

3393999015252



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
50 32




9628.42-003

3393999039975



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
40 40




9629.42-003

3393999039982



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A	B		9630.42-003	3393999039999		12 x1
40	50					



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A	B		96302-003	5410905963020		12 x1
30	35					



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A	B		96303-003	5410905963037		12 x1
40	40					



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A	B		96304-003	5410905963044		12 x1
40	40					



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A	B		96305-003	5410905963051		12 x1
35	50					



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A	B	C		9631.42-003	3393999040001		12 x1
35	30	20					




PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A	B	C		9632.42-003	3393999040018		12 x1
40	38	20					



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A	B		96325-003	5410905963259		12 x1
30	35					



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B C
50 40 20



9633.42-003

3393999040025



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
40 35




96330-003

5410905963303



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
40 40



9635.62-003

3393999040032



12 x1

40 40



9635.68-003

3393999040063



12 x1

40 40



9635.69-003

3393999040049



12 x1

40 40




9635.94-003

3393999040056



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
55 45



9636.42-003

3393999040070



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
35 35



96416-003

5410905964164



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
30 50





96418-003

5410905964188



12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A

96



1454.96.66-003

3393992706584



12 x1

96



1454.96.68-003

3393992706607



12 x1

96




1454.96.94-003

3393992706591



12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE - VARNISHED

A

96




1777.96.63-003

3393999014620




12 x1




ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE - VARNISHED

A				
96		1778.96.62-003	3393999014637	12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE - VARNISHED

A				
96		1779.96.62-003	3393999014644	12 x1




ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A				
64		9626.64.68-003	3393999039913	12 x1
96		9626.96.68-003	3393999039920	12 x1
128		9626.128.68-003	3393999039937	12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE


A				
96		9627.96.69-003	3393999039968	12 x1
96		9627.96.70-003	3393999039951	12 x1
96		9627.96.94-003	3393999039944	12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB


A	B				
35	25		1425.35.17-003	3393992536310	12 x1
35	25		1425.35.37-003	3393992536358	12 x1
35	25		1425.35.37-306	3393999018687	6 x6
35	25		1425.35.48-003	3393992536334	12 x1
35	25		1425.35.68-003	3393992536372	12 x1
35	25		1425.35.69-003	3393992536365	12 x1
35	25		1425.35.70-003	3393992536396	12 x1
			1425.35.95-003	3393992536389	12 x1






PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A	B					
30	30		1447.30.37-003	3393992706409		12 x1
30	30		1447.30.37-036	3393999552894		6 x6
30	30		1447.30.61-003	3393992706416		12 x1
30	30		1447.30.61-036	3393999552900		6 x6
30	30		1447.30.62-003	3393992706423		12 x1
30	30		1447.30.62-036	3393999552917		6 x6
30	30		1447.30.66-003	3393992706430		12 x1
30	30		1447.30.66-036	3393999552924		6 x6
30	30		1447.30.70-003	3393992706454		12 x1
30	30		1447.30.70-036	3393999552931		6 x6
30	30		1447.30.94-003	3393992706447		12 x1
30	30		1447.30.94-036	3393999552948		6 x6




PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A	B					
25	30		425.37-003	0083532055519		12 x1
			425.40-003	0083532055557		24 x1
			425.49-003	0083532055595		24 x1




PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A	B					
35	25		430.35.16-003	0083532064481		12 x1
35	25		430.35.16-406	3393999040537		3 x6
35	25		430.35.17-003	0083532064412		12 x1
35	25		430.35.37-003	3393999001316		12 x1
35	25		430.35.61-003	0083532064405		12 x1
35	25		430.35.61-406	3393999040520		3 x6
35	25		430.35.69-003	0083532064290		12 x1
35	25		430.35.70-003	0083532064269		12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A						
25		433.25.17-003	3393992532886		12 x1	
25		433.25.37-003	3393992532787		12 x1	



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
15 22




238.15.16-003

3393992666802



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
20 23



239.20.13-003

3393992666840



12 x1

20 23




239.20.13-406

3393999040544



3 x6



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
20 23



239.20.16-003

3393992666864



12 x1

20 23




239.20.16-406

3393999040513



3 x6



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
20 26



242.20.13-003

3393992666826



12 x1

20 26




242.20.13-036

3393999040636



6 x6



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
32 22




251.32.26-003

3393992666758



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
25 29



254.25.16-003

3393992666772



12 x1

25 29





254.25.16-036

3393999552863



6 x6



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
23 23



279.23.16-003

3393992665782



12 x1

23 23




279.23.69-003

3393992624659



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
30 25




308.30.16-003

0083532059074



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
25 25




309.25.24-003

0083532059081



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
30 22




310.30.83-003

0083532059098



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
35 30




636.35.37-003

3393999567713



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
35 30




636.35.39-003

3393999567706



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
35 30




636.35.66-003

3393999567690



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A B
24 30



1215.50-003

3393992572097



12 x1

24 30




1215.60-003

3393992572103



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
WOODEN KNOB - VARNISHED

A B
42 33




1529.40-003

3393992618337



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
WOODEN KNOB - VARNISHED

A B
34 33



235.30.83/11-003

0083532060841



12 x1

34 33




235.30.83/12-003

0083532060803



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
WOODEN KNOB - VARNISHED

A B
30 30




236.30.83/16-003

0083532067710



12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
WOODEN KNOB - VARNISHED

A B
33 30




237.33.83/16-003


0083532079140




12 x1


 PUXADOR DE MÓVEL
 POMO DE MUEBLE
 KNOB


A	B				
35	27		1201.35.55-003	3393992541321	12 x1


 PUXADOR DE MÓVEL
 POMO DE MUEBLE
 KNOB


A					
30		1230.30.84-003	3393992589262		12 x1
35		1230.35.84-003	3393992589309		12 x1


 PUXADOR DE MÓVEL
 POMO DE MUEBLE
 KNOB


A	B				
30	35		407.30.80-003	0083532053768	12 x1
38	38		407.38.80-003	0083532053812	12 x1
45	42		407.45.80-003	0083532053867	12 x1


 PUXADOR DE MÓVEL
 POMO DE MUEBLE
 KNOB


A	B				
30	25		584.30.89-003	0083532072301	12 x1
45	30		584.45.89-003	0083532072349	12 x1
60	35		584.60.89-003	0083532072394	12 x1


 PUXADOR DE MÓVEL
 POMO DE MUEBLE
 KNOB


A	B				
30	23		585.30.86-003	0083532072448	12 x1
45	25		585.45.86-003	0083532072509	12 x1
60	30		585.60.86-003	0083532072561	12 x1


 PUXADOR DE MÓVEL
 POMO DE MUEBLE
 KNOB

A	B				
30	30		589.30.86-003	0083532072615	12 x1
35	35		589.35.86-003	0083532072646	12 x1
40	37		589.40.86-003	0083532072677	12 x1
45	38		589.45.86-003	0083532075630	12 x1
50	38		589.50.86-003	0083532072707	12 x1



 PUXADOR DE MÓVEL
 POMO DE MUEBLE
 KNOB

A	B				
25	30		597.25.83-003	0083532072974	12 x1
35	35		597.35.83-003	0083532073001	12 x1
50	40		597.50.83-003	0083532073032	12 x1




PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A	B				
25	30		735.25.37-003	0083532056462	12 x1
25	30		735.25.83-003	0083532056486	12 x1
30	33		735.30.37-003	0083532056547	12 x1
30	33		735.30.83-003	0083532056554	12 x1
30	33		735.30.84-003	0083532056561	12 x1




PUXADOR DE MÓVEL
POMO DE MUEBLE
WOODEN KNOB - VARNISHED

A	B				
35	35		741.35.83-003	0083532083147	12 x1
45	40		741.45.83-003	0083532083185	12 x1




PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A	B				
20	25		742.20.86-003	0083532083260	12 x1
25	30		742.25.86-003	0083532083307	12 x1
30	35		742.30.86-003	0083532083338	12 x1
35	40		742.35.86-003	0083532083376	12 x1
40	40		742.40.86-003	0083532083406	12 x1




PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB

A	B				
20	23		743.20.86-003	0083532083451	12 x1
25	33		743.25.86-003	0083532083499	12 x1
30	37		743.30.86-003	0083532083529	12 x1
33	36		743.35.86-003	0083532083567	12 x1
40	43		743.40.86-003	0083532083598	12 x1




PUXADOR DE MÓVEL
POMO DE MUEBLE
WOODEN KNOB - VARNISHED

A					
30		746.30.86-003	0083532083703		12 x1
30		746.30.86-036	3393999040582		6 x6
30		746.30.86-306	3393999018710		6 x6
35		746.35.86-003	0083532083734		12 x1




PUXADOR DE MÓVEL
POMO DE MUEBLE
KNOB


A	B				
29	31		747.86-003	0083532083765	12 x1


 PUXADOR DE MÓVEL
 POMO DE MUEBLE
 KNOB


A	B					
25	25		750.25.86-003	3393992588975		12 x1
30	27		750.30.86-003	3393992588999		12 x1
30	27		750.30.86-036	3393999562770		10 x6
35	30		750.40.86-003	3393992589033		12 x1


 PUXADOR DE MÓVEL
 POMO DE MUEBLE
 KNOB


A	B					
25	26		753.25.84-003	3393992589521		12 x1
30	27		753.30.84-003	3393992589545		12 x1
40	36		753.40.84-003	3393992589583		12 x1


 PUXADOR DE MÓVEL
 POMO DE MUEBLE
 KNOB


A	B					
20	29		818.86V-003	0083532010730		12 x1


 PUXADOR DE MÓVEL
 POMO DE MUEBLE
 WOODEN KNOB - VARNISHED


A	B					
30	40		832.30.83-003	0083532098516		12 x1
40	45		832.40.83-003	0083532098523		12 x1


 PUXADOR DE MÓVEL
 POMO DE MUEBLE
 WOODEN KNOB - VARNISHED


A	B					
34	30		833.80-003	0083532098530		12 x1


 PUXADOR DE MÓVEL
 POMO DE MUEBLE
 WOODEN KNOB - VARNISHED


A	B					
32	35		861.83-003	0083532088968		12 x1


 PUXADOR DE MÓVEL
 POMO DE MUEBLE
 WOODEN KNOB - VARNISHED

A	B					
32	29		862.83-003	0083532089521		12 x1


 PUXADOR DE MÓVEL
 POMO DE MUEBLE
 WOODEN KNOB - VARNISHED

A	B					
35	26		863.83-003	0083532090077		12 x1



PUXADOR DE MÓVEL
POMO DE MUEBLE
WOODEN KNOB - VARNISHED

A B
40 27



864.83-003

0083532090589



12 x1



ASA DE MÓVEL OCO
TIRADOR DE MUEBLE HUECO
HOLLOW HANDLE

A

90		378.90.32-003	0083532050859		12 x1
90		378.90.32-009	3393999133406		12 x1
90		378.90.32-306	3393999018758		6 x6
		378.115.17-003	0083532050620		12 x1
115		378.115.32-003	0083532050651		12 x1
115		378.115.32-009	3393999133420		12 x2
115		378.115.32-036	3393999040605		6 x6
115		378.115.32-306	3393999018765		6 x6
		378.128.32-003	0083532095416		12 x1
145		378.145.32-003	0083532050729		12 x1
145		378.145.32-009	3393999133444		12 x2
160		378.165.32-003	0083532050798		12 x1
160		378.165.32-009	3393999133468		12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A B


64	10		113.64.17-003	3393992532855		12 x1
64	10		113.64.37-003	3393992532817		12 x1
64	10		113.64.48-003	3393992533142		12 x1
64	10		113.64.68-003	3393992532985		12 x1
64	10		113.64.69-003	0083532065075		12 x1
64	10		113.64.70-003	3393992533036		12 x1
64	10		113.64.95-003	3393992533081		12 x1
96	10		113.96.17-003	3393992532862		12 x1
96	10		113.96.37-003	3393992532824		12 x1
96	10		113.96.37-036	3393999040766		6 x6
96	10		113.96.37-306	3393999018703		6 x6
96	10		113.96.48-003	3393992533159		12 x1
96	10		113.96.68-003	3393992532992		12 x1
96	10		113.96.69-003	3393992532947		12 x1
96	10		113.96.70-003	3393992533043		12 x1
96	10		113.96.95-003	3393992533098		12 x1




ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A B


			114.64.37-003	0083532013892		24 x1
			114.64.37-306	0083532055939		6 x6
			114.96.17-003	0083532014141		24 x1
			114.96.37-003	0083532014189		24 x1
128	10		114.128.17-003	0083532015117		12 x1
128	10		114.128.37-003	0083532015124		12 x1


 ASA DE MÓVEL
 TIRADOR DE MUEBLE
 HANDLE


A					
96		1448.96.37-003	3393992706461		12 x1
96		1448.96.61-003	3393992706478		12 x1
96		1448.96.61-036	3393999552818		6 x6
96		1448.96.62-003	3393992706485		12 x1
96		1448.96.62-036	3393999552986		6 x6
96		1448.96.66-003	3393992706492		12 x1
96		1448.96.66-036	3393999552955		6 x6
96		1448.96.70-003	3393992706515		12 x1
96		1448.96.70-036	3393999552962		6 x6
96		1448.96.94-003	3393992706508		12 x1
96		1448.96.94-036	3393999552979		6 x6


 PUXADOR DE MÓVEL ENCASTRAR
 POMO DE MUEBLE ENCASTRAR
 CUPPED HANDLE


A	B				
23	30		153.30.17-003	0083532017869	12 x1
23	30		153.30.37-003	0083532017906	12 x1
32	40		153.40.17-003	0083532017944	12 x1
32	40		153.40.37-003	0083532017982	12 x1


 ASA DE MÓVEL ENCASTRAR
 TIRADOR DE MUEBLE ENCASTRAR
 CUPPED HANDLE


A	B				
22x74	27x80		160.17-003	0083532019337	12 x1
22x74	27x80		160.37-003	0083532019375	12 x1


 ASA DE MÓVEL
 TIRADOR DE MUEBLE
 HANDLE


A					
96		429.96.17-003	3393992537676		12 x1
96		429.96.37-003	3393992537706		12 x1
96		429.96.48-003	3393992537690		12 x1
96		429.96.68-003	3393992537720		12 x1
96		429.96.69-003	3393992537713		12 x1


 ASA DE MÓVEL
 TIRADOR DE MUEBLE
 HANDLE

A					
64		432.37-003	0083532098615		12 x1


 ASA DE MÓVEL
 TIRADOR DE MUEBLE
 HANDLE

A					
32-128		1444.32-128.16-003	3393992706386		12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A

96




1445.96.16-003

3393992706393



12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A

96



257.96.16-003

3393992666963



12 x1

96



257.96.16-405

3393999040568



3 x5

128



257.128.16-003

3393992666987



12 x1

128




257.128.16-405

3393999654734



3 x5



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A

96



258.96.16-003

3393992666031



12 x1

96



258.96.16-405

3393999040551



3 x5

128



258.128.16-003

3393992667007



12 x1

128




258.128.16-405

3393999654741



3 x5



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A

96



259.96.16-003

3393992666925



12 x1

96



259.96.16-036

3393999562763



6 x6

128



259.128.16-003

3393992666949



12 x1

128




259.128.16-036

3393999562756



6 x6



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A

96



306.96.16-003

0083532059050



12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A

96



307.96.24-003

0083532059067



12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A

96




311.96.16-003

3393992573155



12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A

96




312.96.16-003

3393992571335



12 x1



ASA DE MÓVEL ENCASTRAR
TIRADOR DE MUEBLE ENCASTRAR
CUPPED HANDLE

A

76




637.37-003

3393999567744



12 x1



ASA DE MÓVEL ENCASTRAR
TIRADOR DE MUEBLE ENCASTRAR
CUPPED HANDLE

A

76




637.39-003

3393999567737



12 x1



ASA DE MÓVEL ENCASTRAR
TIRADOR DE MUEBLE ENCASTRAR
CUPPED HANDLE

A

76




637.66-003

3393999567720



12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A

110




638.37-003

3393999567775



12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A

110




638.39-003

3393999567768



12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A

110




638.66-003

3393999567751



12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE - VARNISHED

A

64




1137.64.60-003

3393992548542



12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE - VARNISHED

A

96



1252.96.60-003

3393992571403



12 x1

128




1252.128.60-003

0083532001240




12 x1




ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

 **1259.128.60-003** 3393992572059  12 x1




ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A
64  **595.64.86-003** 3393992533494  12 x1
96  **595.96.86-003** 3393992533500  12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A
64  **596.64.83-003** 0083532072844  12 x1
96  **596.96.83-003** 0083532072929  12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A
120  **732.83-003** 0083532082966  12 x1




ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A B
40x90 98x43  **733.83-003** 0083532083031  12 x1




PUXADOR DE MÓVEL ENCASTRAR
POMO DE MUEBLE ENCASTRAR
CUPPED HANDLE

A
42  **734.83-003** 0083532083093  12 x1




ASA DE MÓVEL
TIRADOR DE MUEBLE
KNOB KNOB

A
96  **735.96.37-003** 0083532056394  12 x1
96  **735.96.83-003** 0083532056417  12 x1
96  **735.96.84-003** 0083532056424  12 x1




ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A
120  **830.83-003** 0083532086803  12 x1




ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE - VARNISHED

A				
64		831.64.83-003	0083532030639	12 x1
96		831.96.83-003	0083532030653	12 x1




ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A				
96		837.96.86-003	0083532030677	12 x1
128		837.128.86-003	0083532098547	12 x1




ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A				
		838.64.86-003	3393992533852	12 x1
96		838.96.86-003	3393992533869	12 x1




ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A				
64		860.64.83-003	0083532088647	12 x1
96		860.96.83-003	0083532088678	12 x1




ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A				
120		892.83-003	0083532092132	12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A				
96		894.86-003	0083532075593	12 x1



ASA DE MÓVEL
TIRADOR DE MUEBLE
HANDLE

A				
64		897.64.86-003	0083532075333	12 x1
96		897.96.86-003	0083532075432	12 x1
96		897.96.86-036	3393999040599	6 x6



ENTRADA DE CHAVE
BOCALLAVE
ESCUTCHEON

A				
35		745.86-003	0083532083635	12 x1